

# MT-CNC / MTC200 Transformation Function V15

Description of Functions

DOK-MT\*CNC-TRA\*FKN\*V15-ANW1-EN-P

<b>Title</b>	Transformation Function
<b>Type of document</b>	Description of functions
<b>Documentation type</b>	DOK-MT*CNC-TRA*FKN*V15-ANW1-EN-P
<b>Internal filing</b>	<ul style="list-style-type: none"> <li>Folder 1 / Register 3</li> <li>Drawing number: 109-0668-4195-00 EN/02.98</li> </ul>
<b>Purpose of the document</b>	This document describes the transformation function and the related requirements.

**Configuration control**

Documentation identification of previous releases	Release date	Comment
109-0668-4195-00 EN	02/98	First translation into English

**Copyright** © INDRAMAT GmbH, 1998

Copying this document, and giving it to others and the use or communication of the contents thereof without express authority are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

**Validity** All rights are reserved with respect to the content of this documentation and the availability of the product.

**Published by** INDRAMAT GmbH • Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main  
Phone +49 (0)9352/40-0 • Tx 689421 • Fax +49 (0)9352/40-4885

Dept. ENC (GL)

# Contents

<b>1 Using the Transformation Function</b>	<b>1-1</b>
<b>2 Method of Operation of the Transformation Function</b>	<b>2-1</b>
2.1 Abbreviations .....	2-1
2.2 Transformation.....	2-1
2.3 Automatic Adaptation of the Path Velocity .....	2-2
<b>3 Fictitious Axes</b>	<b>3-1</b>
3.1 Basics.....	3-1
3.2 Axis Meanings of the Real and Fictitious Axes .....	3-1
3.3 Setting the Parameter Values of the Fictitious Axes.....	3-2
3.4 Interface Signals of the Fictitious Axes .....	3-3
3.5 Path Control Points for the Fictitious Axes.....	3-3
<b>4 Setting the Parameter Values of the Transformation Function</b>	<b>4-1</b>
4.1 System Parameters .....	4-1
4.2 Process Parameters .....	4-1
4.3 Axis Parameters.....	4-1
<b>5 NC Programming</b>	<b>5-1</b>
5.1 Calling the Transformation.....	5-1
5.2 NC Commands That Are Not Permitted During Transformation .....	5-1
5.3 Axis Programming.....	5-2
5.4 Automatic Plane Selection .....	5-2
5.5 Zero Offsets .....	5-2
5.6 Tool Corrections.....	5-3
5.7 Diameter Programming.....	5-3
5.8 Axis Transfer.....	5-3
5.9 Reference Spindle for Transformation.....	5-3
<b>6 Exceptions</b>	<b>6-1</b>
6.1 Power-On State.....	6-1
6.2 Control-Reset.....	6-1
6.3 Changing the Mode.....	6-1
6.4 Reverse.....	6-1
6.5 Process Enabling Signal .....	6-1
6.6 Axis Enabling Signal .....	6-1
6.7 Feed and Spindle Override .....	6-1

<b>7 Interface Signals</b>	<b>7-1</b>
<b>8 Typical NC Program</b>	<b>8-1</b>
<b>9 Index</b>	<b>9-1</b>
<b>10 Figures</b>	<b>10-1</b>

# 1 Using the Transformation Function

Face machining of turned parts on turning and grinding machines is the chief application of the „Transformation of Cartesian coordinates into polar coordinates“ function.

That function is particularly useful for milling surfaces on turning machines and for grinding camshafts. Furthermore, the function may also be employed in other applications, such as milling machines with rotary tables or with rotating heads (double swivel head).

A transformation from Cartesian coordinates to polar coordinates makes programming significantly easier because the movements that are to be produced are programmed in a fictitious Cartesian coordinate system, whilst the machine perform the necessary movements in the existing real polar coordinate system.



## 2 Method of Operation of the Transformation Function

### 2.1 Abbreviations

- R1 real linear axis (first real axis)
- R2 real rotary axis (second real axis)
- F1 first fictitious linear axis
- F2 second fictitious linear axis

---

**Note:** These abbreviations are merely used for explanation.

---

### 2.2 Transformation




Fig. 2-1: Fictitious Cartesian coordinates (F1, F2) and real coordinates (R1, R2)

Programming is performed in the fictitious Cartesian coordinate system (F1, F2), whilst the machine movements are performed in the real machine coordinate system (polar coordinates: R1, R2).

R1 is always positive; R2 varies between 0 and 360 degrees.

If the coordinate origin is crossed during a transformation, the controller commands R2 to rotate by 180 degrees at  $F1=F2=R1=0$ .

---

**Note:** The R1 axis must be moved to the positive section ( $R1 > 0$ ) before transformation is switched on.

---

## 2.3 Automatic Adaptation of the Path Velocity

As it is done for milling, the path velocity for the transformation function must be specified via the F value as a relative velocity between tool and workpiece.

The MT-CNC continuously adjusts the path velocity during interpolation to the requirements of the actual path in order to move along the path at the highest velocity possible (taking the programmed path velocity into account).

The automatic adaptation of the path velocity provides the following benefits for the user:

- No restrictions of the working area  
(movements across the coordinate origin are permitted).
- No additional programming and no additional knowledge required (the path velocity must be specified as in the milling process; independently of the actual distance from the coordinate origin).
- No unnecessary time losses  
(due to the automatic adaptation of the path velocity, the controller always moves the related axes at the maximum velocity possible, taking the programmed path velocity into account).
- No sporadic machine standstill  
(the maximum permissible axis velocity and acceleration values will not be exceeded if machining employs tools of a diameter that is different than the originally assumed value).



## 3 Fictitious Axes

### 3.1 Basics

The fictitious axes F1 and F2 are not directly allocated to drives. Instead, they are allocated indirectly via a formula.

The fictitious axes F1 and F2 are required in the transformation function in order to be able to program the movements of the real axes R1 and R2 in a physically non-existent Cartesian coordinate system.

### 3.2 Axis Meanings of the Real and Fictitious Axes

The MT-CNC supports the transformation function for the XY plane (G17). Consequently, the real axes R1 and R2, that participate in the transformation, must have the axis meanings X and C:

General name	Axis meaning	Axis type
R1	X	digital linear axis
R2	C	digital main spindle with rotary axis capability, or digital rotary axis

During transformation, the fictitious linear axes F1 and F2, that are allocated to the transformation function, behave like linear main axes.

General name	Axis meaning	Axis type
F1	X	fictitious linear axis
F2	Y	fictitious linear axis

In order to be able to

- move along a circle,
- to be able to correctly take the tool compensation values into account, and
- to perform a realistic calculation of the resulting axis velocities on the basis of the programmed path velocities,

the MT-CNC assigns the fictitious axis F1 the axis meaning X and the fictitious axis F2 the axis meaning Y.

The last item is particularly significant for movements in space that are performed during transformation. Without that feature, the velocity components of the axes F1 and F2 could not be taken into account in the velocity computation.

## Example

A lathe with integrated Y and C axis and driven tools possesses the following real and fictitious axes:

General name	Programmable axis designation with inactive transformation	Axis designation with inactive transformation	Programmable axis designation with active transformation	Axis designation with active transformation	Axis type
R1	X (axis des. 1) Y (axis des. 2) Z	X Y Z	- Y (axis des. 2) Z	- V Z	dig. linear axis dig. linear axis dig. linear axis
R2	C (axis des. 1) S1 S2	C S1 S2	- - -	C S1 S2	dig. rotary axis dig. main spindle dig. main spindle
F1	-	-	X1 (axis des. 2)	X	fictitious linear axis
F2	-	-	Y1 (axis des. 2)	Y	fictitious linear axis

When transformation is activated, the fictitious linear axes F1 and F2 instead of the main axes X and Y will participate in the interpolation. The Y axis becomes a secondary axis of the axis meaning V.

When transformation is switched off, the NC restores the original state.

**Note:** When the transformation function is employed, the process concerned may not contain an axis of the axis meaning V.

### 3.3 Setting the Parameter Values of the Fictitious Axes

The fictitious axes do not possess their own parameter records. For both fictitious axes, the NC employs the values that are stored for the linear main axis X:

<b>Cxx.016</b>	Max. feed rate	... [mm/min]
<b>Cxx.017</b>	Max. feed rate change w/o ramp	... [mm/min]
<b>Cxx.018</b>	Max. acceleration rate	... [mm/s <sup>2</sup> ]
<b>Cxx.020</b>	Jogging speed	... [mm/min]
<b>Cxx.021</b>	Jogging speed - rapid	... [mm/min]
<b>Cxx.022</b>	Parametric jogging distance	... [mm]
<b>Cxx.023</b>	Pos. travel limit	... [mm]
<b>Cxx.024</b>	Neg. travel limit	... [mm]

Thus, the individual velocity and acceleration values and the travel limits of both fictitious axes are identical.

### 3.4 Interface Signals of the Fictitious Axes

With active transformation, the axis-related interface signals of the associated real axes R1 and R2 are available for the fictitious axes F1 and F2.

### 3.5 Path Control Points for the Fictitious Axes

There are no path control points for the fictitious axes. The path control points always refer to the real axes and may also be interpreted during the execution of the transformation function.



## 4 Setting the Parameter Values of the Transformation Function

### 4.1 System Parameters

Entries in the system parameters are not required for the transformation function and for the fictitious axes F1 and F2.

The fictitious linear axes F1 and F2 do not occupy slots on the APR. As before, up to nine feed axes may exist within a process, irrespective of the fictitious axes. The maximum number of axes remains limited to 20.

---

**Note:** All axes that move in an interpolating way during transformation, must be on an APR. For a lathe, this means that the two real axes R1 (X) and R2 (C) and the Z axis must be accommodated on an APR.

---

### 4.2 Process Parameters

Whether or not the transformation function may be used during the machining process is defined in the process parameters.

**Bxx.035** Cartesian/polar coordinate transformation possible  
Yes / No

The default selection is „No“.

### 4.3 Axis Parameters

The axis designation of the fictitious axes F1 and F2 must be entered under the parameter:

**Cxx.075** Axis designation 2 ... [ ]

of the associated real axes R1 and R2.

The user interface offers the axis parameter for

- analog and digital linear axes,
- analog and digital rotary axes, and for
- digital main spindles with rotary axis capability.

Like any other axis, the fictitious axes may have any name assigned. Like with real axes, each axis designation may only exist once within a process.

Irrespective of the axis meanings, the axis designations of the fictitious axes consist, like the axis designations of the other axes, of an axis letter and, optionally, of an axis index:

Axis designation = axis letter (+ axis index)

Axis letter  $\in \{X, Y, Z, U, V, W, A, B, C\}$

Axis index  $\in \{1, 2, 3\}$

If there is an axis with the axis meaning Y, a second axis designation must be entered for that axis, too (the axis designation 2 may be identical to the axis designation 1). During transformation, that axis may be programmed and moved using the second axis designation.

**Cxx.076** Direction of polar coordinate transformation  
0/1 [ ]

The axis parameter is used for reversing the direction of rotation when the transformation function is active. The default value of that axis parameter is 0.

The user interface shows the axis parameter for

- digital linear axes,
- digital rotary axes and
- digital main spindles with rotary axis capability.

---

**Note:** The transformation function is only available for digital drive combinations:

- digital main spindles with rotary axis capability with digital linear axis, and
  - digital rotary axis (separate drive) with digital linear axis
-

## 5 NC Programming

### 5.1 Calling the Transformation

The transformation function forms a G code group, and has a modal effect.

**G30** De-selection (power-on state)

**G31** Transformation ON

When the transformation function is activated, the MT-CNC automatically triggers a changeover to rotary axis mode. For a lathe with a separate C axis drive, this means that the C axis drive is engaged during the transformation process.

To improve clarity, the G codes for activating and de-activating the transformation function should be programmed in a separate block.

---

**Note:** Prior to activating the transformation, the R1 axis must be moved to the positive section ( $R1 > 0$ ).

---

### 5.2 NC Commands That Are Not Permitted During Transformation

The following list contains all functions that may not be programmed during transformation:

- Thread cutting 'G33'
- Zero shifts 'G50', 'G51', 'G52'  
(provided that shifts are programmed for R1 and R2)
- Tapping 'G63', 'G64', 'G65'  
(provided that the main spindle (that is allocated to R2) is addressed)
- Homing 'G74'  
(provided that homing is specified for the axes F1 and F2)
- Traveling to dead stop 'G75'
- Canceling all axis preloads 'G76'
- Speed limitation 'G92'  
(provided that the speed limitation is for the main spindle that is allocated to R2)
- Feed per revolution 'G95'  
(provided that the feed specification is for the main spindle that is allocated to R2)
- Constant surface speed 'G96',
- Spindle control commands 'M03', 'M04', 'M05', 'M13', 'M14', 'M19'  
(provided that a spindle-related auxiliary function is programmed for the main spindle that is allocated to R2)
- Axis transfer commands 'GAX', 'FAX'  
(provided that the commands have an effect on the axes F1, F2, R1 and R2)

All those functions will interrupt the execution and lead to an error message if they are invoked during the transformation.

## 5.3 Axis Programming

The fictitious axes F1 and F2 may only be programmed and moved when transformation (G31) is selected. During that time, the real axes R1 and R2, that participate in the transformation, may neither be programmed nor moved in manual mode.

Accordingly, the fictitious axes may neither be programmed nor moved in manual mode when transformation is de-selected.

## 5.4 Automatic Plane Selection

When the transformation function is switched on, the NC automatically selects the XY plane (G17). During transformation, the currently active working plane G17 appears in the status display.

After the transformation function has been de-selected, the NC automatically restores the default working plane that is specified in the process parameters.

## 5.5 Zero Offsets

Irrespective of the activity status of the transformation, the zero offset table continually shows all existing real and fictitious axes. The related zero offset values may be edited at any time.

Example

For the lathe in the example of Chapter 3.2, the zero offset table looks like this:

Axis	X/X1	Y/Y1	Z	C	Phi	Comment
.						
G54	0.01	0.0	68.42	0.0	0.0	turning mode milling mode with Y transformation
G55	0.15	0.25	68.42	0.0	0.0	
G56	0.0	0.0	0.0	0.0	0.0	
G57	5.32	23.02	65.0	15.0	15.0	
.						
.						

The structure of the zero offset table depends on the existing axis meanings.

Axis with the same axis meaning share one column.

In our example, this means that the fictitious axis F1 with the axis designation X1 and the real axis R1 with the axis designation X form one column, while the fictitious axis F2 with the axis designation Y1 and the real axis Y form another column.

If there is no axis with the axis meaning Y (which can frequently be found with lathes), the fictitious axis F2 is in its own column.

During transformation, the entered values act on the related fictitious axes. If transformation is inactive, they act on the associated real axes. Accordingly, the values entered under the angle Phi causes the plane spanned by the fictitious axes to be rotated when transformation is active, and causes a rotation within the active working plane when transformation is inactive.

**Note:** Separate workpiece zero points (G54 through G59) should be used if transformation mode requires zero offsets.



When the transformation function is switched on and off, the NC sets the machine zero point G53, which de-activates all zero offsets.

As long as transformation is active, G50, G51, or G52 may not be used for programming zero offsets for the real axes R1 and R2. Any attempt of doing this will result in the NC generating an error message and aborting execution.

The NC responds in the same way if a zero offset is programmed for one of the fictitious axes F1 or F2 while transformation is switched off.

When the transformation function is active, G50 (absolute zero offset) and G51 (incremental zero offset) may, in addition to linear offsets, be used for performing rotations within the plane that is spanned by the fictitious axes.

## 5.6 Tool Corrections

When the transformation function is switched on and off, the NC de-activates tool length and tool radius correction.

Tool length and tool radius correction may already be active when transformation is switched on. Its operation is not influenced by the transformation function.

---

**Note:** Only tools of type 1 or 2 may be used during transformation.  
If the utilization of a type 4 tool (angle-head tool) is absolutely necessary, the tool length correction values L1 and L2 must be taken into account in geometry programming. A value 0 must be entered for the corresponding tool length correction values L1 and L2 of the tool.

---

## 5.7 Diameter Programming

When the transformation function is switched on, the NC automatically selects radius programming (G15).

When the transformation function is switched off, the NC restores the programming type that has been stored in the process parameters: G15 programming type (radius programming) or G16 (diameter programming).

---

**Note:** If G16 (diameter programming) is selected during transformation, the NC interprets all position values of the fictitious axis F1 as diameter specifications.

---

## 5.8 Axis Transfer

Neither the fictitious axes F1 and F2 nor the real axis R2 can be transferred between the processes.

## 5.9 Reference Spindle for Transformation

Within a given process, the transformation function can only be active once. It may be related, however, to spindle 1, 2 or 3, or to the associated rotary axes (R2) with the axis meanings A, B or C.

The associated rotary axes may not be declared as auxiliary axes (axis meaning U, V or W).

Provided it is not yet the reference spindle, the reference spindle that is valid for transformation may be selected via the SPC (spindle selection for

Cartesian/polar transformation) command before or during transformation.

Using the SPF command, the reference spindle for feed programming during tapping (G63, G64, G65) and for speed limitation (G92) may be switched over even when the transformation function is active.

## 6 Exceptions

### 6.1 Power-On State

The transformation function is always inactive (G30) when the controller is switched on.

### 6.2 Control-Reset

Each reset de-activates the transformation function (G30).

### 6.3 Changing the Mode

The NC does not reset the transformation function when the mode is changed or during jogging in manual mode.

### 6.4 Reverse

A reverse does not have any effect on the transformation function. Merely a homing of the fictitious axes F1 and F2 interrupts execution and causes an error message to be issued (with active or inactive transformation).

The real axes R1 and R2 may only be homed when transformation is inactive.

### 6.5 Process Enabling Signal

When the process enabling signal is switched off, the NC shows the same behavior for active and for inactive transformation.

### 6.6 Axis Enabling Signal

The NC interprets the axis enabling signal of the real axes in manual mode only.

### 6.7 Feed and Spindle Override

Feed override always acts upon the axes that participate in path interpolation. (and thus indirectly upon the real axes R1 and R2), and on the other axes that participate in interpolation.

Like in C axis mode, spindle override is not taken into account.



## 7 Interface Signals

**PxxSTRANS** 0: Transformation is not active  
1: Transformation is active

The „transformation is active“ status signal tells the SPS whether or not the transformation function is currently active in the NC.

The NC updates the status signal in all modes.



## 8 Typical NC Program




Fig. 8-1: Facing with transformation

<b>NC program</b>	T12 BSR .M6	;Changing driven tool
	BSR .M89	;Engaging driven tool
	S2 3500 M203	;Driven tool ON
	G00 Z10	
	X50 C0	;Basic position for changeover
	G31	;Switch on transformation
	G54 G00 G90 G17 G06 G08 G48	;Initial position
	X1 60 Y1 20	;[P1] Machining starting point
	G01 Z-0.5 F500	;Infeed Z axis
	G42 X1 20 Y1 60 F400	;[P2] 1st straight line
	X1 -20	;[P3] 2nd straight line
	X1 -50 Y1 30	;[P4] 3rd straight line
	G03 X1 -50 Y1 -30 I-50 J0	;[P5] CCW semi circle
	G01 X1 -20 Y1 -60	;[P6] 4th straight line
	X1 20	;[P7] 5th straight line
	X1 60 Y1 -20	;[P8] 6th straight line
	Y1 20	;[P1] 7th straight line
	G00 Z10	;Z axis to safety distance
	G30	;De-selecting Transformation
	G54 G48 G00 X130	;Initial position
	Z200	;Withdraw Z axis
	RET	;End of program





# 9 Index

## A

Automatic adaptation of the path velocity	2-2
Automatic plane selection	5-2
Axis enabling signal	6-1
Axis meanings of the real and fictitious axes	3-1
Axis parameters	4-1
Axis programming	5-2
Axis transfer	5-3

## B

Bxx.035	4-1
---------	-----

## C

Calling the transformation	5-1
Changing the mode	6-1
Control-Reset	6-1
Cxx.075	4-1
Cxx.076	4-1

## D

Diameter programming	5-3
----------------------	-----

## F

F1	3-1
F2	3-1
Facing with transformation	8-1
Feed and spindle override	6-1
Fictitious axes	3-1
Axis meaning	3-1
Interface signals	3-3
Path Control Points	3-3
Setting parameter values	3-2
Fictitious Cartesian coordinates	2-1

## G

G30	5-1
G31	5-1

## I

Interface signals	7-1
Interface signals of the fictitious axes	3-3

## M

Method of operation of the transformation function	2-1
--	-----

## N

NC commands that are not permitted during transformation	5-1
NC programming	5-1

## P

Path control points for the fictitious axes	3-3
Power-on state	6-1
Process enabling signal	6-1
Process parameters	4-1
PxxSTRANS	7-1

## R

R1	3-1
R2	3-1
Real axes	3-1

Axis meaning	3-1
Real coordinates	2-1
Reference spindle for transformation	5-3
Reverse	6-1
<b>S</b>	
Setting the parameter values of the fictitious axes	3-2
Setting the parameters of the transformation function	4-1
System parameters	4-1
<b>T</b>	
Tool corrections	5-3
Transformation	2-1
<b>U</b>	
Using the transformation function	1-1
<b>Z</b>	
Zero offsets	5-2

## 10 Figures

Fig. 2-1: Fictitious Cartesian coordinates (F1, F2) and real coordinates (R1, R2) ..	2-1
Fig. 8-1: Facing with transformation	8-1



# List of Customer Service Points

## Germany

<b>Sales area Center</b> INDRAMAT GmbH D-97816 Lohr am Main Bgm.-Dr.-Nebel-Str. 2 Phone: 09352/40-0 Fax: 09352/40-4885	<b>Sales area East</b> INDRAMAT GmbH D-09120 Chemnitz Beckerstraße 31 Phone: 0371/3555-0 Fax: 0371/3555-230	<b>Sales area West</b> INDRAMAT GmbH D-40849 Ratingen Hansastraße 25 Phone: 02102/4318-0 Fax: 02102/41315	<b>Sales area North</b> INDRAMAT GmbH D-22085 Hamburg Fährhausstraße 11 Phone: 040/227126-16 Fax: 040/227126-15
<b>Sales area South</b> INDRAMAT GmbH D-80339 München Ridlerstraße 75 Phone: 089/540138-30 Fax: 089/540138-10	<b>Sales area South-West</b> INDRAMAT GmbH D-71229 Leonberg Böblinger Straße 25 Phone: 07152/972-6 Fax: 07152/972-727		<b>INDRAMAT Service Hotline</b> INDRAMAT GmbH Phone: D-0172/660 040 6 -or- Phone: D-0171/333 882 6

Customer service points in Germany

## Europe

<b>Austria</b> G.L.Rexroth Ges.m.b.H. Geschäftsbereich INDRAMAT A-1140 Wien Hägelingasse 3 Phone: 1/9852540-400 Fax: 1/9852540-93	<b>Austria</b> G.L.Rexroth Ges.m.b.H. Geschäftsbereich INDRAMAT A-4061 Pasching Randlestraße 14 Phone: 07229/64401-36 Fax: 07229/64401-80	<b>Belgium</b> Mannesmann Rexroth N.V.-S.A. Geschäftsbereich INDRAMAT B-1740 Ternat Industrielaan 8 Phone: 02/5823180 Fax: 02/5824310	<b>Denmark</b> BEC Elektronik AS DK-8900 Randers Zinkvej 6 Phone: 086/447866 Fax: 086/447160
<b>United Kingdom</b> Mannesmann Rexroth Ltd. INDRAMAT Division Cirencester, Glos GL7 1YG 4 Esland Place, Love Lane Phone: 01285/658671 Fax: 01285/654991	<b>Finland</b> Rexroth Mecman OY SF-01720 Vantaa Riihimiehentie 3 Phone: 0/848511 Fax: 0/846387	<b>France</b> Rexroth - Sigma S.A. Division INDRAMAT F-92632 Gennevilliers Cedex Parc des Barbanniers 4, Place du Village Phone: 1/41475430 Fax: 1/47946941	<b>France</b> Rexroth - Sigma S.A. Division INDRAMAT F-69634 Venissieux - Cx 91, Bd 1 Joliot Curie Place du Village Phone: 78785256 Fax: 78785231
<b>France</b> Rexroth - Sigma S.A. Division INDRAMAT F-31100 Toulouse 270, Avenue de l'ardenne Phone: 61499519 Fax: 61310041	<b>Italy</b> Rexroth S.p.A. Divisione INDRAMAT I-20063 Cernusco S/N.MI Via G. Di Vittoria, 1 Phone: 02/92365-270 Fax: 02/92108069	<b>Italy</b> Rexroth S.p.A. Divisione INDRAMAT Via Borgomanero, 11 I-10145 Torino Phone: 011/7712230 Fax: 011/7710190	<b>Netherlands</b> Hydraudyne Hydrauliek B.V. Kruisbroeksestraat 1a P.O. Box 32 NL-5280 AA Boxtel Phone: 04116/51951 Fax: 04116/51483
<b>Spain</b> Rexroth S.A. Centro Industrial Santiago Obradors s/n E-08130 Santa Perpetua de Mogoda (Barcelona) Phone: 03/718 68 51 Telex: 591 81 Fax: 03/718 98 62	<b>Spain</b> Goimendi S.A. División Indramat Jolastokieta (Herrera) Apartado 11 37 San Sebastian, 20017 Phone: 043/40 01 63 Telex: 361 72 Fax: 043/39 93 95	<b>Sweden</b> AB Rexroth Mecman INDRAMAT Division Varuvägen 7 S-125 81 Stockholm Phone: 08/727 92 00 Fax: 08/64 73 277	<b>Switzerland</b> Rexroth SA Département INDRAMAT Chemin de l'Ecole 6 CH-1036 Sullens Phone: 021/731 43 77 Fax: 021/731 46 78
<b>Switzerland</b> Rexroth AG Geschäftsbereich INDRAMAT Gewerbestraße 3 CH-8500 Frauenfeld Phone: 052/720 21 00 Fax: 052/720 21 11	<b>Russia</b> Tschudnenko E.B. Arsenia 22 153000 Ivanovo Rußland Phone: 093/22 39 633		

European customer service points without Germany

## Outside Europe

<p><b>Argentina</b></p> <p>Mannesmann Rexroth S.A.I.C. Division INDRAMAT Acassuso 48 41/7 1605 Munro (Buenos Aires) Argentina</p> <p>Phone: 01/756 01 40 01/756 02 40 Telex: 262 66 rexro ar Fax: 01/756 01 36</p>	<p><b>Argentina</b></p> <p>Nakase Asesoramiento Tecnico Diaz Velez 2929 1636 Olivos (Provincia de Buenos Aires) Argentina Argentina</p> <p>Telefon 01/790 52 30</p>	<p><b>Australia</b></p> <p>Australian Industrial Machinery Services Pty. Ltd. Unit 3/45 Horne ST Campbellfield VIC 2061 Australia</p> <p>Phone: 03/93 59 0228 Fax: 03/93 59 02886</p>	<p><b>Brazil</b></p> <p>Mannesmann Rexroth Automação Ltda. Divisão INDRAMAT Rua Georg Rexroth, 609 Vila Padre Anchieta BR-09.951-250 Diadema-SP Caixa Postal 377 BR-09.901-970 Diadema-SP</p> <p>Phone: 011/745 90 65 011/745 90 70 Fax: 011/745 90 50</p>
<p><b>Canada</b></p> <p>Basic Technologies Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8</p> <p>Phone: 905/335-55 11 Fax: 905/335-41 84</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. Shanghai Office Room 206 Shanghai Intern. Trade Centre 2200 Yanan Xi Lu Shanghai 200335 P.R. China</p> <p>Phone: 021/627 55 333 Fax: 021/627 55 666</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. Shanghai Parts &amp; Service Centre 199 Wu Cao Road, Hua Cao Minhang District Shanghai 201 103 P.R. China</p> <p>Phone: 021/622 00 058 Fax: 021/622 00 068</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. 1430 China World Trade Centre 1, Jianguomenwai Avenue Beijing 100004 P.R. China</p> <p>Phone: 010/50 50 380 Fax: 010/50 50 379</p>
<p><b>China</b></p> <p>Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District Dalian 116 023 P.R. China</p> <p>Phone: 0411/46 78 930 Fax: 0411/46 78 932</p>	<p><b>Hong Kong</b></p> <p>Rexroth (China) Ltd. 19 Cheung Shun Street 1st Floor, Cheung Sha Wan, Kowloon, Hong Kong</p> <p>Phone: 741 13 51/-54 and 741 14 30 Telex: 3346 17 GL REX HX Fax: 786 40 19 786 07 33</p>	<p><b>India</b></p> <p>Mannesmann Rexroth (India) Ltd. INDRAMAT Division Plot. 96, Phase III Peenya Industrial Area Bangalore - 560058</p> <p>Phone: 80/839 21 01 80/839 73 74 Telex: 845 5028 RexB Fax: 80/839 43 45</p>	<p><b>Japan</b></p> <p>Rexroth Co., Ltd. INDRAMAT Division I.R. Building Nakamachidai 4-26-44 Tsuzuki-ku, Yokohama 226 Japan</p> <p>Phone: 045/942-72 10 Fax: 045/942-03 41</p>
<p><b>Korea</b></p> <p>Rexroth-Seki Co Ltd. 1500-12 Da-Dae-Dong Saha-Gu, Pusan, 604-050</p> <p>Phone: 051/264 90 01 Fax: 051/264 90 10</p>	<p><b>Korea</b></p> <p>Seo Chang Corporation Ltd. Room 903, Jeail Building 44-35 Yoido-Dong Youngdeungpo-Ku Seoul, Korea</p> <p>Phone: 02/780-82 07 ~9 Fax: 02/784-54 08</p>	<p><b>Mexico</b></p> <p>Motorización y Diseño de Controles, S.A. de C.V. Av. Dr. Gustavo Baz No. 288 Col. Parque Industrial la loma Apartado Postal No. 318 54060 Tlalnepantla Estado de Mexico</p> <p>Phone: 5/397 86 44 Fax: 5/398 98 88</p>	
<p><b>USA</b></p> <p>Rexroth Corporation INDRAMAT Division 5150 Prairie Stone Parkway Hoffman Estates, Illinois 60192</p> <p>Phone: 847/645-36 00 Fax: 857/645-62 01</p>	<p><b>USA</b></p> <p>Rexroth Corporation INDRAMAT Division 2110 Austin Avenue Rochester Hills, Michigan 48309</p> <p>Phone: 810/853-82 90 Fax: 810/853-82 90</p>		

Customer service points outside Europe

**Notes**

