



# ECODRIVE03

## Drive For General Automation With Profibus Interface

Firmware Version Notes: FGP-01VRS

DOK-ECODR3-FGP-01VRS\*\*-FVN1-EN-P

<b>Titel</b>	ECODRIVE03 Drive For General Automation With Profibus Interface
<b>Type of Documentation</b>	Firmware-Versionnote FWA-ECODR3-FGP-01VRS-MS
<b>Documentation code</b>	DOK-ECODR3-FGP-01VRS**-FVN1-EN-P
<b>Internal filing notation</b>	<ul style="list-style-type: none"> <li>• Mappe 73-01V-EN / Register 10</li> <li>• Based on: FGP 01V</li> <li>• 209-0088-4335-01</li> </ul>
<b>What is the purpose of this documentation</b>	<p>This documentation is a supplement to the function description DOK-ECODR3-FGP-01VRS**-FKB1-EN-P: Drive For General Automation With Profibus Interface.</p> <p>It describes the differences between ECODRIVE3-Version FWA-ECODR3-FGP-01VRS and FWA-ECODR-PDP-03VRS.</p>

**Editing sequence**

Document identification of previous and present editions	Release Date	Note
DOK-ECODR3-FGP-01VRS**-FVN1-EN-P	04.98	first release

<b>Copyright</b>	<p>© INDRAMAT GmbH, 1998</p> <p>Transmission as well as reproduction of this documentation, commercial use or communication of its contents will not be permitted without expressed written permission. Violation of these stipulations will require compensation. All rights reserved for the ensurance of the patent or registered design. (DIN 34-1)</p>
<b>Liability</b>	Changes in the content of the documentation and the delivery possibilities of the products are reserved
<b>Publisher</b>	<p>INDRAMAT GmbH • Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main</p> <p>Telephone 09352/40-0 • Tx 689421 • Fax 09352/40-4885</p> <p>Abt. ECD (WR/HP)</p>
<b>Note</b>	This document is printed on chlorine-free bleached paper.

# Contents


<b>1 General Information</b>	<b>1-1</b>
1.1 Product Family .....	1-1
1.2 Documentation .....	1-1
1.3 Notes on Replacing the Firmware.....	1-2
<b>2 Version Notes FWA-ECODRV3-FGP-01VRS-MS</b>	<b>2-1</b>
2.1 Release notes .....	2-1
2.2 New functions.....	2-1
Error Memory and Operating Hour Counter.....	2-1
New Component to Communicate with the Parameter Interface.....	2-1
Permanently configured status messages .....	2-2
Language switch to French, Spanish and Italian.....	2-2
Motor Types .....	2-3
Operating Modes.....	2-3
Measuring Systems.....	2-4
Current Limits.....	2-5
Drive-Side Error Reaction .....	2-6
Automatic Control Loop Settings.....	2-6
Velocity Mix Factor .....	2-6
Analog Inputs .....	2-7
Oscilloscope Function .....	2-7
Probe Function.....	2-7
Detect Marker Position Command.....	2-7
Park Axis Command .....	2-8
Dynamic Programmodule Limit Switch (PLS).....	2-8
Encoder Emulation.....	2-8
2.3 Expanded/Changed Functions.....	2-9
Password.....	2-9
Command Communication via Profibus.....	2-9
Positioning Block Mode .....	2-9
Jogging.....	2-10
Travel range limit.....	2-10
E-Stop Function.....	2-10
Controller Structure .....	2-10
Velocity Control Loop Monitoring .....	2-12
Drive Halt.....	2-12
Drive-Controlled Referencing.....	2-12
Analog Output .....	2-12
Serial Communication .....	2-13



# 1 General Information

## 1.1 Product Family

The product release description refers to the product family:



The following drive controls can be operated with this software:

- DKC03.3

This document describes the differences between ECODRIVE03 version FWA-ECODR3-FGP-01VRS and the previous ECODRIVE version FWA-ECODR-PDP-03VRS.

## 1.2 Documentation

The documentation for product **FWA-ECODR3-FGP-01VRS** is available as follows:

- Paper form
- Windows help system

The following table contains a summary of available items.

POS	Type	Document style	Register in Mapped	Part number	Symbol number
1	DOK-ECODR3-FGP-01VRS**-73M1-EN-P	Mappe 73-01V-EN	--	279102	209-0088-4331-01
2	DOK-ECODR3-FGP-01VRS**-FKB1-EN-P	Functional Description Paper	3	279103	209-0088-4332-01
3	DOK-ECODR3-DKC**.3****-PRJ1-EN-P	Project Planning	7	279714	209-0088-4301-01
4	DOK-ECODR3-FGP-01VRS**-WAR1-EN-P	Trouble Shooting GuidePaper	10	279104	209-0088-4334-01
5	DOK-ECODR3-FGP-01VRS**-FVN1-EN-P	Firmware Versionsnote	11	280278	209-0088-4335-01
6	DOK-ECODR3-FGP-01VRS**-73M1-EN-H1,44	Help System for Windows3.1 Disk	12	279105	209-0088-4331-01

Fig. 1-1: Documentation for FWA-ECODR3-FGP-01VRS

## 1.3 Notes on Replacing the Firmware

Prior to replacing the firmware, the following points must be noted:

1. The drive controller is on.
2. Secure the current parameters.
3. Switch the controller into phase 2.
4. Replace firmware with Dolfi,  
SWA-DOL\*PC-INB-01VRS-MS-C1.44-COPY, parst number 279804.

---

**Note:** 24V control voltage may not be switched off during the firmware exchange procedure.

---

- a) Switch drive into phase 2.
- b) Start Dolfi.
- c) Input the following under specified settings:
  - **Interface:**
    - select interface (COM 1 - 4)
    - set baudrate for Connect to 9.6 kB (always)
    - set baudrate for download (9.6 to 115 kB)
  
  - **Addresses**
    - Set **Sender** to value < 128
      - do not select the address set on programming module via switches S2 and S3
      - Sender and receiver addresses must be different.
    - Set **receiver** to value < 128
      - do not select the address set on programming module via switches S2 and S3
      - Sender and receiver addresses must be different.
    - Enter the address set via switches S2 and S3 into field **unit address**.
  
  - **Language**
    - Select language (German/English)
- d) press connect button  
→ Header of the programmed module is read out.
  - Look at header by selecting the header button.
  - then change into window messages by selecting the message button
- e) Press transmit button  
→ \*.ibf-file for update must be selected

- f) Start firmware update with ok (must be pressed after every programmed firmware module, generally, one FWA contains three firmware modules).
  - g) Press separate button after successful update  
→ drive firmware is started
  - h) end Dolfi
5. If the number of parameters to be backed up has changed, then "PL" appears in the display. (If errors are pending, then these must be cleared first). If the S1 key is now pressed, then all backed up parameters are set to their default values. During this time "C8 load default parameters" appears on the display.
  6. If command "C8 load default parameters" was started or the motor type changed, then "UL" appears prior to transition check from phase 3 to 4. The S1 key must now be pressed, or the command clear error started. The control default settings are then loaded out of the motor feedback into the drive controller.
  7. Load the desired parameter file.





## 2 Version Notes FWA-ECODRV3-FGP-01VRS-MS

### 2.1 Release notes

Firmware version **FWA-ECODR3-FGP-01V02** represents the first official edition of version 01. It was released on

18.05.1998

The following drive controllers can be operated with the released software:

- DKC03.3-040-7-FW
- DKC03.3-100-7-FW

---

**Note:** To commission the drive firmware version **FWA-ECODRV03-FGP-01VRS-MS** then DriveTop version **SWA-DTOP\*\*\*-INB-05VRS-MS-C1,44-COPY** is needed.

---

### 2.2 New functions

#### Error Memory and Operating Hour Counter

Operating hour counters and error memory were used in the past to store class 1 diagnostics errors and the number of operating hours of the machine in the form of parameters:

- **P-0-0190, Operating hours control section**
- **P-0-0191, Operating hours power section**
- **P-0-0192, Error recorder, diagnosis number**
- **P-0-0193, Error recorder, operating hours control section**

These are stored in the amplifier EEPROM. The user can not write access them.

#### New Component to Communicate with the Parameter Interface

##### Additional ID number lists

For communication between drive firmware and parameter interface, new ID number lists have been introduced:

- **S-0-0018, IDN-list of operation data for CP2**
- **S-0-0019, IDN-list of operation data for CP3**
- **S-0-0025, IDN-list of all procedure commands**
- **S-0-0292, List of all operating modes**

### Identifying the Writability of a Parameter in Attribute

In bits 28..30 the information as to in which communications phase a parameter is write accessible is stored.

Bit no. in attribute	Definition
28	0 - writable in comm. phase 2 1 - not writable in comm. phase 2
29	0 - writable in comm. phase 3 1 - not writable in comm. phase 3
30	0 - writable in comm. phase 4 1 - not writable in comm. phase 4

Fig. 2-1:

### List of diagnosis numbers

To display the previously generated diagnoses for errors, warning, command errors, commands and operating states of the drive, parameter **S-0-0375, List of diagnostic numbers** is used.

## Permanently configured status messages

In parameter **S-0-0013, Class 3 diagnostics** and **S-0-0182, Manufacturer class 3 diagnostics** the following general and operating-mode specific status messages have been newly implemented.

In **S-0-0013, Class 3 diagnostics** :

- actual velocity = command velocity
- $| \text{actual velocity} | < \text{velocity threshold}$
- $| M_d | > M_{d\text{grenz}}$
- target position reached

In **S-0-0182, Manufacturer class 3 diagnostics** :

- IZP (Zielposition erreicht & IN\_POSITION & IN\_STANDSTILL)
- IN\_TARGETPOSITION
- drive halt acknowledge
- End position reached

## Language switch to French, Spanish and Italian

The following languages for parameter names and units as well as diagnoses in parameter **S-0-0095, Diagnostic message** are in the drive.

S-0-0265, Language selectionl	Language selected
0	German
1	English
2	French
3	Spanish
4	Italien

Fig. 2-2: Language selection in S-0-0265, *Language selectionl*

## Motor Types

In addition to the synchronous motors MKD, the following synchronous and asynchronous motors can also be operated.

<b>MHD</b>	<b>LAF/LAR</b>
<b>MKE</b>	<b>LSF</b>
<b>2AD/1MB/ADF</b>	<b>MBS</b>
<b>synchronous kit motor</b>	

MHD, MKD and MKE motors are automatically detected and the needed motor parameters set. All other motor types must be set by inputting the relevant parameters.

### Motor holding brake control

Parameters

- **P-0-0525, Type of motor brake**
- **P-0-0526, Brake control delay** are used to control the holding brake.

These parameters are automatically set in MHD, MKD and MKE motors. The brake current is not monitored.

### Load-side motor encoder in rotary asynchronous motors

If motor type "2" or "6" is set (rotary asynchronous motor), then the motor encoder can be mounted load side and operated there as well. The load side motor encoder is parametrized with parameters from encoder 2 (optional encoder):

- **S-0-0115, Position feedback 2 type**
- **S-0-0117, Feedback 2 Resolution**
- **P-0-0075, Feedback type 2**

**P-0-0074, Feedback type 1** must be parametrized with "0". Parameter **P-0-0121, Velocity mix factor Feedback 1 & 2** must be set to 100%.

## Operating Modes

Four operating modes, i.e., the main and three auxiliary operating modes, can be simultaneously selected on the drive. Which of these four modes is to be active can be selected in the master control word. Both setting and selection can generally be viewed in the Profibus protocol or the higher-ranking control.

The following operating modes can be set in the drive:

- torque control
- velocity control
- *position control with cyclical position command default* (do not use with non-synchronized Profibus communication)
- (absolute) drive-internal interpolation
- relative drive-internal interpolation
- positioning block mode
- jogging

**Note:** The parametrization of **P-0-4084, Operation mode selection code** determines that operating mode that is activated with active Profibus communications. Only a reduced number of operating modes can be selected.

## Measuring Systems

Up to two measuring systems can be simultaneously evaluated and used. One measuring system is used as motor encoder. The other is evaluated as an optional encoder. The operating mode selected determines the measuring system used to close the position control loop. In parameter **P-0-0121, Velocity mix factor Feedback 1 & 2** the actual velocity value can be mixed in velocity control.

The following table describes which measuring system is evaluated at which interface.

Measuring system	Interface	Value P-0-0074/75
digital servo feedback or resolver	1	1
Incremental encoder with sine signals from Heidenhain with 1V signals	2	2
Incremental encoder with square-wave signals from Heidenhain	2	5
Encoder with EnDat-interface	2	8
Gearwheel encoder with 1Vss signals	2	9
resolver without feedback memory	1	10
Resolver without feedback memory + Incremental encoder with sine signals	1 + 2	11
Hall encoder + square-wave encoder	1 + 2	12
ECl encoderr	1	13

Fig. 2-3: Measuring systems > connections

### Absolute Encoder

Both motor encoder and optional encoders can be absolute encoders. Whether the measuring system is evaluated as an absolute encoder or not, depends on

- the travel range set in **S-0-0278, Maximum travel range** (with absolute format of position data) or
- the modulo value set in **S-0-0103, Modulo value** (with modulo format of position data).

This means it is now possible:

- to handle singleturn encoders as absolute encoders and
- to switch absolute encoder evaluation for multiturn encoders off

### Programmable drive-internal position resolution

The resolution of the drive-internal position data is no longer dependent on the motor encoder type, but can be set via parameter **S-0-0278, Maximum travel range**. The maximum resolution is  $2^{15}$  per encoder period, minimum  $2^2$ . The computed resolution for encoders 1 and 2 is displayed in parameters **S-0-0256, Multiplication 1** und **S-0-0257, Multiplication 2**.

---

**Note:** The drive-internal position resolution mentioned here does not here the format and unit in which the position data are displayed. This is still set in parameter **S-0-0076, Position data scaling type**.

---

The drive-side resolution in form of the number of increments per motor revolution of a rotary motor encoder, for example, is computed in terms of **S-0-0116, Feedback 1 Resolution \* S-0-0256, Multiplication 1**.

The function supports

- the increase of drive-internal resolution of position data with small travel paths and high resolution requirements as well as
- to decrease the resolution in favor of the possible travel range.

---

**Note:** The per "Load default value" activated resolution generally meets demands in terms of possible travel range with sufficiently large position resolution.

---

## Current Limits

The dynamic current limit no longer implements the overload factor **P-0-0006, Overload factor**, but rather the temperature model of the amplifier powerstage and the motor. In parameter **P-0-4046, Active peak current** maximum available current, including limits, is displayed by the dynamic current limit. In **P-0-4045, Active permanent current** the available continuous current is displayed. This value depends on the set switching frequency.

### Monitoring Amplifier Overload

**Monitoring thermal controller load with a temperature model of the endstage**

The thermal load of the controller endstage is performed with a temperature model. The thermal load is displayed in parameter **P-0-0141, Thermal drive load**. It is no longer necessary to make a setting in a parameter. If the drive limits the effective peak current because of the amplifier overload, then warning **E257 Continuous current limit active** is generated and bit 0 (overload warning) is set in **S-0-0012, Class 2 diagnostics**.

### Monitoring Motor Overload

**Monitoring thermal motor load with temperature model of motor**

For 400msec the fourfold motor standstill current is allowed. The 2.2 fold is continuously allowed. If the motor overload limit is active, then warning **E225 Motor overload** is generated and bit 0 (overload warning) is set in **S-0-0012, Class 2 diagnostics**.

## Drive-Side Error Reaction

The reaction of the drive to detected errors has been expanded as follows:

- Via parameter **P-0-0119, Best possible deceleration** the reaction of the drive to non-fatal and interface errors can be set. In addition to the reactions "Velocity command to zero" and "Torque to zero", "Velocity to zero with ramp and filter" and "Jerk limit" are also used.
- "NC reaction with error". If a non-fatal error occurs, then the drive error reaction can be delayed by 30 seconds. Setting in parameter **P-0-0117, NC reaction on error**.
- In parameter **P-0-0118, Power off on error** settings can be made for a) the time that power should be switched on, b) shutdown of power with fault, c) execution of a package reaction and d) reaction of the drive to DC bus undervoltage.

## Automatic Control Loop Settings

With the automatic control loop settings, the velocity and position control loops are completely automatically parametrized.

This uses a new command "**D900 Command automatic loop tuning**" in the drive.

In conjunction with Drivetop the command "D9 Automatic control loop settings" can be started in the Drivetop dialog "Parameter / Automatic control loop settings".

The user can effect, via the so-called attenuating factor, the resulting control loop dynamics. This means that no further control technical knowledge is needed to make control loop settings.

Additionally, at the end of the control loop setting, the determined load moment of inertia and the maximum parametrizable accel are displayed and stored in a parameter.

---

**Note:** To optimize the control loop, it is necessary to move an axis!

---

## Velocity Mix Factor

With the help of the velocity mix factor, the actual velocity value used for velocity control can be put together based on motor and external measuring systems. This can be advantageous with coupling units between motor and load that are characterized by backlash or torsion.

To set the mixing relationship, use parameter **P-0-0121, Velocity mix factor Feedback 1 & 2**

## Analog Inputs

With the function *Analog inputs* it is possible:

- enter some parameters of the drive with variable scaling via analog/digital converters. (Parameter **P-0-0212, Analog inputs, IDN list of assignable parameters**, **P-0-0213, Analog input 1, assignment**, **P-0-0214, Analog input 1, scaling per 10V full scale**, **P-0-0215, Analog input 2, assignment** and **P-0-0216, Analog input 2, scaling per 10V full scale**, new).
- The analog input signals have an offset (parameter **P-0-0217, Analog input 1, offset** and **P-0-0218, Analog input 2, offset** new)

Analog input 1 is processed every 500 usec, 2 only every 8 msec.

## Oscilloscope Function

With the oscilloscope function, specific signals of the drive such as

- **S-0-0051, Position feedback 1 value** or **S-0-0053, Position feedback 2 value**,
- **S-0-0040, Velocity feedback value**
- **S-0-0080, Torque/Force command**
- **S-0-0347, Speed deviation**
- **S-0-0189, Following error**

can be stored in 2\*512-deep measurand lists. Triggering results either from external or thresholds that can be parametrized in the drive for position, velocity or torque data. By using the triggering stipulations, reading the measurand list and graphically illustrating the measurands stored therein by means of a parametrization interface, an oscilloscope function can be implemented. Superimposing the measuring results of axes interpolating with each other, it is possible to illustrate contour accuracy.

## Probe Function

There are two probe inputs on the drive. This function stores signals from:

- actual position values or
- relative drive-internal time

at the time the switching edge of this probe occurs. They are stored in the relevant parameters. By preselecting, it is fixed whether the positive or negative edge of the probe is evaluated. Each time the edge occurs, the difference between the measurand for the positive and that of the negative edge is stored in the parameter for the measurand difference.

## Detect Marker Position Command

With command **P-0-0014, D500 Command determine marker position** the correct detecting and the position of the reference marker of an incremental measuring system can be detected. The position of the marker is displayed in parameter **S-0-0173, Marker position A**. The command is also used to operate gantry axes with external measuring systems as well as to examine the error-free detection of reference markers.

## Park Axis Command

Command **S-0-0139, D700 Command Parking axis** was used. Write access to this command is only possible in communications phase 2. If this command is activated, then all the monitoring activities of the command **S-0-0128, C200 Communication phase 4 transition check** are not conducted. Message "PA" appears on the 7-segment display. A phase regression deactivates this command (as is the case with all other commands).

## Dynamic Programmable Limit Switch (PLS)

With the function dynamic Programmablr limit switch, up to 8 position-dependent cams can be realized. The actual position value 1 can be used as reference signal (motor encoder) or that of 2 (optional encoder ). There is one on and one off threshold for each cam. If an off threshold is smaller than the on threshold, then the cam is inverted. There is also for each cam a separately programmable prehold time with which the reference signal can be corrected in terms of the velocity.

## Encoder Emulation

With function encoder emulation it is possible to emulate

- actual position value 1
- and actual position value 2 or
- the command position value in the form of
- SSI signals or
- TTL signals (incremental encoder).



## 2.3 Expanded/Changed Functions

### Password

The password function has been modified so that

- by inputting a customer password, not all parameters of the drive become write protected but instead only those parameters that are in parameter **S-0-0192, IDN-list of backup operation data**. These are precisely those parameters stored in the programming module.

### Command Communication via Profibus

Communications via Profibus has been modified:

- Profibus DP is absolute required, Profibus FMS optional, possible for parametrization of the drive. Also, a parameter channel can be opened via the protocol DP.
- A **freely-configurable process data channel** of up to 16 words in both data directions via FMS objects 6000 and 6001.
- Similar to drive profile **DRIVECOM Profil 22** for drive functions position target setting.
- Automatic baudrate detection
- For setting operating mode via **P-0-4084, Operation mode selection code**, the following are possible:

Select code in P-0-4084	Function
0xFF80	I/O moe, compatible to Ecodrive01
0x0001	position target setting similar to <b>DRIVECOM Profil 22</b>

Fig. 2-4: Select operating mode in FGP-01VRS

### Positioning Block Mode

The following modifications have been made in positioning block mode:

- the switch-signal dependent following block expansion commutation always brings about a commutation to the next (cam 1) or penultimate (cam 2) positioning block, in terms of the positioning block selected in parameter **P-0-4026, Process block selection**. The commutation relates absolutely to the positioning block selected in P-0-4026. In firmware version ECODRV-PDP-03VRS this switching signal commutation always related to the current positioning block. Any bouncing of the cam meant that further commutations could occur.
- Activating mode „*Slow travel*“ is set in bit 1 of parameter **P-0-4060, Process block control word** and no longer in **P-0-4027, Function parameter**.
- Relative positioning is performed with or without residual path storage. Any break in a relative positioning block with residual path storage will not lose the reference dimension of the sequence.

## Jogging

If communications uses a Profibus and not a 16 bit I/O mode, than jogging can only be activated if the drive halt signal is on „1“ (not active). The parameters for accel and jerk limits during operation are

- **S-0-0260, Positioning Acceleration** and
- **S-0-0193, Positioning Jerk.**

**Note:** It is no longer possible to activate „*Travel slow*“ in jog mode. ebsart! The velocity set in **P-0-4030, Jog velocity** always applies.

## Travel range limit

Whether the travel range limit switch input is active or not can be checked in parameter **P-0-0222, Status Inputs travel range limits**.

## E-Stop Function

The E-Stop function was changed so that

- in bit 1 and 2 of **P-0-0008, Activation E-Stop function** the reaction of the drive upon actuation of the E-stop input can be selected and
- the status of the E-stop input (active / not active) is displayed in parameter **P-0-0223, Status Input E-Stop function**.




Fig. 2-5: P-0-0008, Activation E-Stop function

## Controller Structure

The velocity controller has been modified so that

- the deep pass filter of the actual velocity value is dropped in parameter **S-0-0392, Velocity feedback filter**,
- the variables (torque command) generated by the velocity controller can be filtered over a bandstop filter with programmable frequencies and bandwidth (Parameter **P-0-0180, Rejection frequency velocity loop** and **P-0-0181, Rejection bandwidth velocity loop** new) and
- the deep pass can be set via **P-0-0004, Velocity loop smoothing time constant** to not effect the variables but rather the control deviations of the velocity controller.




Fig. 2-6: Control structure FWA-ECODRV3-FGP-01VRS

Fp5007f1.fh7

- S-0-0189 Following error
- S-0-0348 Acceleration feedforward prop. gain
- P-0-0004 Velocity loop smoothing time constant
- P-0-0121 Velocity mixfactor feedback 1 & 2
- P-0-0180 Rejection frequency velocity loop
- P-0-0181 Rejection bandwidth velocity loop
- P-0-4046 Active permanent current

- S-0-0080 Torque/force command
- S-0-0084 Torque/force feedback value
- S-0-0091 Bipolar velocity limit value
- S-0-0100 Velocity loop proportional gain
- S-0-0101 Velocity loop integral action time
- S-0-0106 Current loop proportional gain 1
- S-0-0107 Current loop integral action time 1

- S-0-0032 Primary mode of operation
- S-0-0036 Velocity command value
- S-0-0037 Additive velocity command value
- S-0-0040 Velocity feedback value
- S-0-0047 Position command value
- S-0-0051 Position feedback 1 value
- S-0-0053 Position feedback 2 value

- P-0-0421/424 d: velocity command value
- P-0-0420/423 S-0-0036

ID no. and designation of signal for analog output

## Velocity Control Loop Monitoring

The velocity control loop monitor can be switched off with bit 8 of parameter **P-0-0538, Motor function parameter 1**.

## Drive Halt

The drive brings itself to a stop taking accel and jerk limit values into account:

Previous operating state	Parameters usedr
no position control mode	P-0-1201, ramp-1, P-0-1203, ramp-2, P-0-1202, transition velocity
position control with drive-internal interpolation (pos. block mode, rive-internal interpol. relative drive-internal interpolation)	previous accel and jerk limit remains active
position control without drive-internal interpolation	S-0-0138, bipolar accel S-0-0349, bipolar jerk limit

Fig. 2-7: Accel and jerk with drive halt

## Drive-Controlled Referencing

The function *Drive-controlled referencing* has been expanded:

- Encoder 1 (motor encoder) and 2 (optional encoder) can be referenced.
- encoder with distance-coded reference marker is possible
- via bit 7 in parameter **S-0-0147, Referenzfahr-Parameter** it can be selected whether the drive will go to the reference point or stands still after switching into the actual value coordinate system.

## Analog Output

The analog output function has been altered and expanded with:

- Specific drive parameters can be output with variable scaling via digital/analog converter. (Parameter **P-0-0426, Analog outputs, IDN list of assignable parameters, P-0-0420, Analog output 1 signal selection, P-0-0422, Analog output 1, scaling per 10V full scale and P-0-0425, Analog output 2, evaluation, new**).
- Bits and bytes that can be output via the expanded signal selected are. (parameter **P-0-0421 Analog output 1, expanded signal selection and P-0-0424 Analog output 2, expanded signal selection new**).

Signal no. P-0-0421/424	Output signal	Reference unit: eval. factor 1.0
0x00000001	sine signal motor encoder	0.5V/10V
0x00000002	cosine signal motor encoder	0.5V/10V
0x00000003	sine signal ext. Encoder	0.5V/10V
0x00000004	cosine signal ext. Encoder	0.5V/10V
0x00000005	command pos. difference on position controller	rot. =>1000rpm/10V lin. =>100m/min/10V
0x00000006	DC bus power	1kW/10V
0x00000007	DC bus power absolute amount	1kW/10V
0x00000008	rms current (Iq)	S-0-0110/10V
0x00000009	Blind current (Id)	S-0-0110/10V
0x0000000a	Thermal load	--
0x0000000b	Motor temperature	150°C/10V
0x0000000c	Magnetization current	S-0-0110/10V
0x0000000d	veloc. command value on speed controller	rot. =>1000rpm/10V lin. => 100m/min/10V
0x0000000e	Bleeder load	100 % / 10V

Fig. 2-8: Signal select list with predefined signal selection

- These outputs are scaling-independent and always relate to the motor shaft. The scaling of the signals is possible in terms of the evaluation parameters P-0-0422&P-0-0425. They are, with the expanded signal selection with predefined signals, fixed as a factor with four decimal places and have a permanent reference unit to the selected signal (see table).

## Serial Communication

The serial communications with drive via the serial interface can implement either (connector X2):

- an ASCII protocol (see Ecodrive-1) or
- via SIS protocol (**S**erial **I**ndronat-**S**chnittstelle)

The protocol is automatically identified.



# Customer Service Locations - Sales & Service Facilities

## Deutschland - Germany

Vertriebsgebiet Mitte Germany Centre <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service	Vertriebsgebiet Ost Germany East <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service	Vertriebsgebiet West Germany West <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service	Vertriebsgebiet Nord Germany North <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service
<b>INDRAMAT GmbH</b> Bgm.-Dr.-Nebel-Str. 2 D - 97816 Lohr on Main Telefon: +49 (0)9352/40-0 Telefax: +49 (0)9352/40-4885	<b>INDRAMAT GmbH</b> Beckerstraße 31 D - 09120 Chemnitz Telefon: +49 (0)371/35 55-0 Telefax: +49 (0)371/35 55-333	<b>INDRAMAT GmbH</b> Harkortstraße 25 D - 40849 Ratingen Telefon: +49 (0)2102/43 18-0 Telefax: +49 (0)2102/41 315	<b>INDRAMAT GmbH</b> Kieler Straße 212 D - 22525 Honburg Telefon: +49 (0)40/85 31 57-0 Telefax: +49 (0)40/85 31 57-15
<b>Vertriebsgebiet Süd</b> Germany South <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service	<b>Gebiet Südwest</b> Germany South-West <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service		<b>INDRAMAT Service-Hotline</b> <b>INDRAMAT GmbH</b> Telefon: (+49)-0172/660 04 06 -oder- Telefon: (+49)-0171/333 88 26
<b>INDRAMAT GmbH</b> Ridlerstraße 75 D-80339 München Telefon: +49 (0)89/540138-30 Telefax: +49 (0)89/540138-10	<b>INDRAMAT GmbH</b> Böblinger Straße 25 D-71229 Leonberg Telefon: +49 (0)7152/9 72-6 Telefax: +49 (0)7152/9 72-727		

Kundenbetreuungsstellen in Deutschland - Service agencies in Germany

## Europa - Europe

<p><b>Austria</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth Ges.m.b.H. Geschäftsbereich INDRAMAT Hägelingasse 3 A - 1140 Wien</p> <p>Telefon: +43 (0)1/9852540-400 Telefax: +43 (0)1/9852540-93</p>	<p><b>Austria</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth G.m.b.H. Geschäftsbereich INDRAMAT Industriepark 18 A - 4061 Pasching</p> <p>Telefon: +43 (0)7221/605-0 Telefax: +43 (0)7221/605-21</p>	<p><b>Belgium</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth N.V.-S.A. Geschäftsbereich INDRAMAT Industrielaan 8 B-1740 Ternat</p> <p>Telefon: +32 (0)2/5823180 Telefax: +32 (0)2/5824310</p>	<p><b>Denmark</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>BEC AS Zinkvej 6 DK-8900 Randers</p> <p>Telefon: +45 (0)87/11 90 60 Telefax: +45 (0)87/11 90 61</p>
<p><b>England</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Ltd. INDRAMAT Division 4 Esland Place, Love Lane GB - Cirencester, Glos GL7 1YG</p> <p>Telefon: +44 (0)1285/658671 Telefax: +44 (0)1285/654991</p>	<p><b>Finland</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Rexroth Mecman OY Ansatie 6 SF-017 40 Vantaa</p> <p>Telefon: +358 (0)9/84 91 11 Telefax: +358 (0)9/84 91 13 60</p>	<p><b>France</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Sigma S.A. Division INDRAMAT Parc des Barbanniers 4, Place du Village F-92632 Gennevilliers Cedex</p> <p>Telefon: +33 (0)141 47 54 30 Telefax: +33 (0)147 94 69 41</p>	<p><b>France</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Rexroth - Sigma S.A. Division INDRAMAT 270, Avenue de Lardenne F - 31100 Toulouse</p> <p>Telefon: +33 (0)5 61 49 95 19 Telefax: +33 (0)5 61 31 00 41</p>
<p><b>Italy</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione INDRAMAT Via G. Di Vittoria, 1 I - 20063 Cernusco S/N.MI</p> <p>Telefon: +39 (0)2/92 36 52 70 Telefax: +39 (0)2/92 36 55 12</p>	<p><b>Italy</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione INDRAMAT Via Borgomanero, 11 I - 10145 Torino</p> <p>Telefon: +39 (0)11/7 71 22 30 Telefax: +39 (0)11/7 71 01 90</p>	<p><b>Italy</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione INDRAMAT Via del Progresso, 16 (Zona Ind.) I - 35020 Padova</p> <p>Telefon: +39 (0)49/8 70 13 70 Telefax: +39 (0)49/8 70 13 77</p>	<p><b>Italy</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione INDRAMAT Via de Nicola, 12 I - 80053 Castellonare di Stabia NA</p> <p>Telefon: +39 (0)81/8 72 30 37 Telefax: +39 (0)81/8 72 30 18</p>
<p><b>Italy</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione INDRAMAT Viale Oriani, 38/A I - 40137 Bologna</p> <p>Telefon: +39 (0)51/34 14 14 Telefax: +39 (0)51/34 14 22</p>	<p><b>Netherlands</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Hydraudyne Hydrauliek B.V. Kruisbroeksestraat 1 P.O. Box 32 NL - 5281 RV Boxtel</p> <p>Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/65 14 83</p>	<p><b>Netherlands</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Hydrocare B.V. Kruisbroeksestraat 1 P.O. Box 32 NL - 5281 RV Boxtel</p> <p>Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/67 78 14</p>	<p><b>Spain</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A. Division INDRAMAT Centro Industrial Santiga Obradors s/n E-08130 Santa Perpetua de Mogoda Barcelona</p> <p>Telefon: +34 937 47 94 00 Telefax: +34 937 47 94 01</p>
<p><b>Spain</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Goimendi S.A. División Indronat Jolastokieta (Herrera) Apartado 11 37 E - 20017 San Sebastian</p> <p>Telefon: +34 9 43/40 01 63 Telefax: +34 9 43/39 17 99</p>	<p><b>Sweden</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Rexroth Mecman Svenska AB INDRAMAT Division Varuvägen 7 S - 125 81 Stockholm</p> <p>Telefon: +46 (0)8/727 92 00 Telefax: +46 (0)8/64 73 277</p>	<p><b>Switzerland - West</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth SA Département INDRAMAT Chemin de l'Ecole 6 CH-1036 Sullens</p> <p>Telefon: +41 (0)21/731 43 77 Telefax: +41 (0)21/731 46 78</p>	<p><b>Switzerland - East</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth AG Geschäftsbereich INDRAMAT Gewerbstraße 3 CH-8500 Frauenfeld</p> <p>Telefon: +41 (0)52/720 21 00 Telefax: +41 (0)52/720 21 11</p>
<p><b>Russia</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Tschudnenko E.B. Arsenia 22 RUS - 153000 Ivanovo Rußland</p> <p>Telefon: +7 093/223 96 33 oder/for +7 093/223 95 48 Telefax: +7 093/223 46 01</p>	<p><b>Slowenia</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>DOMEL Elektromotorji in gospodinjnski aparati d. d. Otoki 21 SLO - 64 228 Zelezniki</p> <p>Telefon: +386 64/61 73 32 Telefax: +386 64/64 71 50</p>	<p><b>Turkey</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Hidropar A..S. Fevzi Cakmak Cad No. 3 TR - 34630 Sefaköy Istanbul</p> <p>Telefon: +90 212/541 60 70 Telefax: +90 212/599 34 07</p>	

Europäische Kundenbetreuungsstellen (ohne Deutschland)  
European Service agencies (without Germany)



## Außerhalb Europa - outside Europe

<b>Argentina</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Mannesmann Rexroth S.A.I.C. Division INDRAMAT Acassuso 48 41/7 RA - 1605 Munro (Buenos Aires) Telefon: +54 (0)1/756 01 40 +54 (0)1/756 01 36	<b>Argentina</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service NAKASE Asesoramiento Tecnico Calle 49, No. 5764-66 RA - 1653 Villa Balester Provincia de Buenos Aires Telefon: +54 (0) 1/768 24 13 Telefax: +54 (0) 1/768 36 43	<b>Australia</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service AIMS - Australian Industrial Machinery Services Pty. Ltd. Unit 3/45 Horne ST Conpbellfield 3061 AUS - Melbourne, VIC Telefon: +61 (0)3/93 59 02 28 Telefax: +61 (0)3/93 59 02 66	<b>Brazil</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Mannesmann Rexroth Automação Ltda. Divisão INDRAMAT Rua Georg Rexroth, 609 Vila Padre Anchieta BR - 09951-270 Diadema-SP [ Caixa Postal 377 ] [ BR-09901-970 Diadema-SP ] Telefon: +55 (0)11/745 90 60 +55 (0)11/745 90 70 Telefax: +55 (0)11/745 90 50
<b>Canada</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Basic Technologies Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8 Telefon: +1 905/335 55 11 Telefax: +1 905/335-41 84	<b>China</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. Shanghai Office - Room 206 Shanghai Internat. Trade Centre 2200 Yanan Xi Lu PRC - Shanghai 200335 Telefon: +86 21/62 75 53 33 Telefax: +86 21/62 75 56 66	<b>China</b> <input type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. Shanghai Parts & Service Center 199 Wu Cao Road, Hua Cao Minhang District PRC - Shanghai 201 103 Telefon: +86 21/62 20 00 58 Telefax: +86 21/62 20 00 68	<b>China</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. 15/F China World Trade Center 1, Jianguomenwai Avenue PRC - Beijing 100004 Telefon: +86 10/65 05 03 80 Telefax: +86 10/65 05 03 79
<b>China</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District PRC - Dalian 116 023 Telefon: +86 411/46 78 930 Telefax: +86 411/46 78 932	<b>Honkong</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Rexroth (China) Ltd. 19 Cheung Shun Street 1st Floor, Cheung Sha Wan, Kowloon, Honkong Telefon: +852 27/41 13 51/-54 oder/or +852 27/41 14 30 Telefax: +852 27/86 07 33	<b>India</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Mannesmann Rexroth (India) Ltd. INDRAMAT Division Plot. 96, Phase III Peenya Industrial Area IND - Bangalore - 560058 Telefon: +91 (0)80/8 39 21 01 Telefax: +91 (0)80/8 39 43 45	<b>India</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Mannesmann Rexroth (India) Ltd. INDRAMAT Division Plot. A-58, TTC Industrial Area Thane Turbhe Midc Road Mahape Village IND - Navi Mumbai - 400 701 Telefon: +91 (0)22/7 61 46 22 Telefax: +91 (0)22/7 68 15 31
<b>Indonesia</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service PT. Rexroth Wijayakusuma Jl. Raya Bekasi Km 21 Pulogadung RI - Jakarta Timur 13920 Telefon: +62 21/4 61 04 87 +62 21/4 61 04 88 Telefax: +62 21/4 60 01 52	<b>Japan</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Rexroth Automation Co., Ltd. INDRAMAT Division 1F, I.R. Building Nakonachidai 4-26-44 Tsuzuki-ku, Yokohona-shi J - Kanagawa-ken 224-004 Telefon: +81 459/42-72 10 Telefax: +81 459/42-03 41	<b>Korea</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Mannesmann Rexroth-Seki Co Ltd. 1500-12 Da-Dae-Dong ROK - Saha-Ku, Pusan, 604-050 Telefon: +82 (0)51/2 60 06 18 Telefax: +82 (0)51/2 60 06 19	<b>Korea</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Seo Chang Corporation Ltd. Room 903, Jeail Building 44-35 Yeouido-Dong Yeoungdeungpo-Ku C.P.O.Box 97 56 ROK - Seoul Telefon: +82 (0)2/7 80 82 08 +82 (0)2/7 80 82 09 Telefax: +82 (0)2/7 84 54 08
<b>Mexico</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Motorización y Diseño de Controles SA de CV Ant. Conino a Sta. Monica No. 7 San Lucas Tepetlcalco MEX - 54060 Tlalnepantla Telefon: +52 53/97 86 44 Telefax: +52 53/98 98 88	<b>New Zealand</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service Engineering Computer Services Ltd. P. O. box 20 204 Te Rapa NZ - Honilton Telefon: +64 (0)7/8 49 22 11 Telefax: +64 (0)7/8 49 22 20	<b>South Africa</b> <input checked="" type="checkbox"/> V/S <input checked="" type="checkbox"/> Service HYTEC Automation (Pty) Ltd. 28 Banfield Road, Industria North RSA - Maraisburg 1700 Telefon: +27 (0)11/673 20 80 Telefax: +27 (0)11/673 72 69	<b>Taiwan</b> <input checked="" type="checkbox"/> V/S <input type="checkbox"/> Service Rexroth Uchida Co., Ltd. No.1, Tsu Chiang Street Tu Cheng Ind. Estate Taipei Hsien, Taiwan, R.O.C. Telefon: +886 2/2 68 13 47 Telefax: +886 2/2 68 53 88

Kundenbetreuungsstellen außerhalb Europa - Service agencies outside Europe

**Außerhalb Europa / USA - outside Europe / USA**

<p>USA <span style="float: right;">☑ V/S ☑ Service</span></p> <p>Mannesmann Rexroth Corporation INDRAMAT Division 5150 Prairie Stone Parkway USA - Hoffman Estates, IL 60192-3707</p> <p>Telefon: +1 847/6 45 36 00 Telefax: +1 857/6 45 62 01</p>	<p>USA <span style="float: right;">☑ V/S ☑ Service</span></p> <p>Mannesmann Rexroth Corporation INDRAMAT Division Central Region Technical Center USA - Auburn Hills, MI 48326</p> <p>Telefon: +1 248/3 93 33 30 Telefax: +1 248/3 93 29 06</p>	<p>USA <span style="float: right;">☑ V/S ☑ Service</span></p> <p>Mannesmann Rexroth Corporation INDRAMAT Division Southeastern Technical Center 3625 Swiftwater Park Drive USA - Suwanee Georgia 30174</p> <p>Telefon: +1 770/9 32 32 00 +1 770/9 32 19 03</p>	<p>USA <span style="float: right;">☑ V/S ☑ Service</span></p> <p>Mannesmann Rexroth Corporation INDRAMAT Division Northeastern Technical Center 99 Rainbow Road USA - East Granby, Connecticut 06026</p> <p>Telefon: +1 860/8 44 83 77 +1 860/8 44 85 95</p>
<p>USA <span style="float: right;">☑ V/S ☑ Service</span></p> <p>Mannesmann Rexroth Corporation INDRAMAT Division Charlotte Regional Sales Office 14001 South Lakes Drive USA - Charlotte, North Carolina 28273</p> <p>Telefon: +1 704/5 83 97 62 +1 704/5 83 14 86</p>			

Kundenbetreuungsstellen außerhalb Europa / USA  
- Service agencies outside Europe / USA

## Notes

