

SERCANS
SERCOS interface Assembly
Firmware-Version FWA-SERCAN-SER-05VRS-MS

Title SERCANS SERCOS interface Assembly

Type of documentation Firmware release

Document code DOK-SERCAN-SER-05VRS**-FV01-EN-P

Internal file reference

- INDRAMAT BBS (Products→controls→SERCANS→version05)
- File name: SCS05E_V.DOC
- Document no. 120-2000-B303-01/EN

Purpose of document? This document is a supplement to application of description SERCANS SERCOS interface Assembly, (version 05VRS), doc. no.: DOK-SERCAN-SER-05VRS**-AW01-EN-P.

Editing sequence

| Firmware status | Release | Comment |
|----------------------|----------|---------------------------------------|
| FWA-SERCAN-SER-05VRS | 17.12.99 | 1 st release of version 05 |
| | | |
| | | |

Copyright © REXROTH INDRAMAT GmbH, 1999

Transmission as well as reproduction of this documentation, commercial use or communication of its contents will not be permitted without expressed written permission. Violation of these stipulations will require compensation. All rights reserved for the issuance of the patent or registered design. (DIN 34-1)

Validity All rights are reserved with respect to the content of this documentation and the availability of the product.

Published by REXROTH INDRAMAT GmbH
 Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main
 Telephone 09352/40-0 • Tx 689421 • Fax 09352/40-4885
<http://www.rexroth.com/indramat>
 Dept. ESP (JL)

Note This document has been printed on chlorine-free bleached paper.

Contents

| | |
|--|------------|
| 1 General Information | 1-1 |
| 1.1 Product Family | 1-1 |
| 1.2 Referenced Hardware | 1-1 |
| 1.3 Referenced Firmware | 1-1 |
| 2 Firmware Version FWA-SERCAN-SER-05VRS | 2-1 |
| 2.1 Release Notes..... | 2-1 |
| 2.2 How to Replace the Firmware..... | 2-1 |
| Sequence for Firmware Exchange with Initial Status 02/03/04VRS | 2-1 |
| 2.3 Checking the Hardware Version | 2-1 |
| 3 New Functions | 3-1 |
| 3.1 Command Value Generator Position Control..... | 3-1 |
| Reversing | 3-1 |
| Step-Mode..... | 3-2 |
| 3.2 Real Time Bits of the Oscilloscope Function | 3-3 |
| 3.3 Noise Generator..... | 3-4 |
| 3.4 List of Measured Values | 3-5 |
| 3.5 New Monitor Functions | 3-6 |
| 3.6 New Interrupts in the Status Register | 3-6 |
| 3.7 SERCOS Interface Version V01.1 | 3-7 |
| 3.8 Validity of AT Data in the Actual Value Channel | 3-7 |
| 4 New or Altered Parameters | 4-1 |
| Y-0-0001 Bus mode | 4-1 |
| Y-0-0044 Command value generator enable | 4-2 |
| Y-0-0045 Command value generator operating mode axis structure 1 | 4-3 |
| Y-0-0046 Command value generator operating mode axis structure 2 | 4-4 |
| Y-0-0047 Command value generator operating mode axis structure 3 | 4-4 |
| Y-0-0048 Command value generator operating mode axis structure 4 | 4-5 |
| Y-0-0049 Command value generator operating mode axis structure 5 | 4-5 |
| Y-0-0050 Command value generator operating mode axis structure 6 | 4-5 |
| Y-0-0051 Command value generator operating mode axis structure 7 | 4-6 |
| Y-0-0052 Command value generator operating mode axis structure 8 | 4-6 |
| Y-0-0053 Command value generator control word | 4-6 |
| Y-0-0054 Command value generator position 1 translatory..... | 4-7 |
| Y-0-0055 Command value generator position 2 translatory..... | 4-8 |
| Y-0-0056 Command value generator velocity translatory | 4-8 |

Y-0-0057 Command value generator dwell time 4-9

Y-0-0058 Command value generator jogging speed translatory..... 4-9

Y-0-0059 Command value generator status word 4-10

Y-0-0060 Command value generator position 1 rotary 4-11

Y-0-0061 Command value generator position 2 rotary 4-12

Y-0-0062 Command value generator velocity rotary 4-12

Y-0-0063 Command value generator jogging speed rotary 4-13

Y-0-0064 Command value generator travel distance translatory..... 4-13

Y-0-0065 Command value generator travel distance rotary 4-14

Y-0-0066 List of telegram type parameter..... 4-14

Y-0-0067 Amplitude noise source 4-16

Y-0-0068 List of scope data 1 noise source 4-16

Y-0-0069 Positioning acceleration translatory..... 4-17

Y-0-0070 Positioning acceleration rotary 4-17

Y-0-0071 Powering up target phase..... 4-18

Y-0-0072 List of scope data 2 noise source..... 4-18

Y-0-0073 List of error counter AT 4-19

5 Kundenbetreuungsstellen - Sales & Service Facilities

5-1

1 General Information

1.1 Product Family

This is a firmware version of description of product family:

SERCANS SERCOS interface Assembly.

Current firmware version: FWA-SERCAN-SER-05VRS-MS

1.2 Referenced Hardware

Allowed hardware for the SERCANS modules

| | | |
|-----------|-----------|-----------|
| SCS A01.2 | SCS P01.2 | |
| SCS A02.1 | SCS P02.1 | SCS V02.1 |

1.3 Referenced Firmware

| Product | Product Firmware |
|-----------|-------------------------------|
| SCS-P01.2 | FWA-SERCAN-SER-05VRS-MS-FLASH |
| SCS-P02.1 | |
| SCS-A01.2 | |
| SCS-A02.1 | |
| SCS-V02.1 | |

Fig. 1-1: Referenced firmware

2 Firmware Version FWA-SERCAN-SER-05VRS

2.1 Release Notes

SERCANS firmware version FWA-SERCAN-SER-05VRS-MS-FLASH was released on

December 17, 1999.

2.2 How to Replace the Firmware

Sequence for Firmware Exchange with Initial Status 02/03/04VRS

To replace the firmware, follow the steps in the order specified and comply with the instructions:


1. Before installing the new firmware, secure all Y parameters with all of the DriveTop user surface.
2. After the Y parameters are secure, install the new firmware on the SERCANS module.
3. Check hardware version as specified in '*Check hardware version*'.
4. Then load the Y parameters with DriveTop back on.
5. Version 05VRS contains, in comparison to version 02VRS/03VRS/04VRS several additional or altered parameters. SERCANS set these to their default values (see section '*New or altered parameters*').

2.3 Checking the Hardware Version

The exchange of SERCANS firmware can mean the loss of the hardware version which is stored in the E²-Prom.


Use the following to perform this task:

- Terminal emulator (e.g., hyper terminal is available in Windows)
- SERCANS – monitor cable 1 (available from dept. customer service)



The procedure of described here makes it possible for the user to check and correct the hardware version:

- Make a note of the hardware version. It is on the barcode sticker on the underside of the SERCANS module. (Example: SCS-P01.2A-FW)
- Connect PC and SERCANS module with plug VS7 using a SYSDA 2.1 cable. Make sure that the red cable marking is inserted into plug contact 1 (contact 1 is identified with a triangle on the printed circuit board).
- Start terminal emulator. The following settings are necessary:
- 9600 baud / 8 data bits / no parity / 1 stopbit / no protocol
- Start the SCS-P, if there is on.
- The SERCANS monitor signals after start or with this menu after pressing the appropriate key:




```

SERCANS - HyperTerminal
Datei Bearbeiten Ansicht Agruf Übertragung ?
[Icons]
SYS>
IAM MON165 (large) V1.1 Fri. 08. Sep 1995 12:37 (c) IAM NOMUX_16
hardware version: SERCPC V1.2
software version: 2.09
version date: 09/15/97
version time: 15:14:13
SERCANS>
Verbunden 00.05.05 Autom. Erkenn. 9600 8-N-1

```

First, the E²-Prom has to be initialized. To do this, enter *initeep* and conclude with the enter key.

Now set the five last places of the hardware version. For example, with "SCS-P01.2A-FW" enter *hw 01.2A* and conclude with enter:



```

SERCANS - HyperTerminal
Datei Bearbeiten Ansicht Agruf Übertragung ?
[Icons]
SYS>
IAM MON165 (large) V1.1 Fri. 08. Sep 1995 12:37 (c) IAM NOMUX_16
hardware version: SERCPC V1.1
software version: 2.09
version date: 09/15/97
version time: 15:14:13
SERCANS>hw 01.2A
Hardwareversion : SCS-P01.1A
Softwareversion : SERCAN-SER-02V09
Hardwareversion : SCS-P01.2A
Softwareversion : SERCAN-SER-02V09
SERCANS>
Verbunden 00.01.20 Autom. Erkenn. 9600 8-N-1

```

- End monitor program.

3 New Functions

3.1 Command Value Generator Position Control

Reversing

Function When reversing in "position control" mode the drive moves as illustrated below.




Fig. 3-1: Reversing with position control

The drive reverses between positions x_1 and x_2 .

Starting with the present position, the drive accelerates to "command value generator velocity translatory" (Y-0-0056) or "command value generator velocity rotary" (Y-0-0062). The rise of velocity depends on "positioning acceleration translatory" (Y-0-0069) or "positioning acceleration rotary" (Y-0-0070) and "position command value smoothing filter time constant" (P-0-0099).

After "command value generator dwell time" (Y-0-0057) the rotational direction is reversed.

Activation Reverse is only possible as long as drive enable is activated. If removed, then the drive is stopped.

Parameters The following parameters can be set with translatory axes:

- "Command value generator position 1 translatory" (Y-0-0054)
- "Command value generator position 2 translatory" (Y-0-0055)
- "Command value generator velocity translatory" (Y-0-0056)
- "Positioning acceleration translatory" Y-0-0069)
- "Position command value smoothing filter time constant" (P-0-0099)
- "Command value generator dwell time" (Y-0-0057)

The following parameters can be set with rotary axes:

- "Command value generator position 1 rotary" (Y-0-0060)
- "Command value generator position 2 rotary" (Y-0-0061)
- "Command value generator velocity rotary" (Y-0-0062)
- "Positioning acceleration rotary" (Y-0-0070)
- "Position command value smoothing filter time constant" (P-0-0099)
- "Command value generator dwell time" (Y-0-0057)

Step-Mode

- Relative motion** Starting with the present position, a relative motion is being conducted with travel path Δx . The direction is specified by the sign of Y-0-0064 or Y-0-0065.
- Function** Step mode in "position control" mode results, for example, in the following motion:




Fig. 3-2: Step-mode with position control

First there is acceleration, starting from present position, whilst taking into account "positioning acceleration translatory" (Y-0-0069) or "positioning acceleration rotary" (Y-0-0070) and "position command value smoothing filter time constant" (P-0-0099) to "command value generator velocity translatory" (Y-0-0056) or "command value generator velocity rotary" (Y-0-0062).

The drive precisely runs to position Y-0-0064/Y-0-0065.

After "command value generator dwell time" (Y-0-0057), the procedure is repeated.

- Activation** Step mode is only possible if the drive enable is activated. If it is removed, then the drive is stopped.
- Parameter** The following parameters can be set with translatory axes:
- "Command value generator travel distance translatory" (Y-0-0064)
 - "Command value generator velocity translatory" (Y-0-0056)
 - "Positioning acceleration translatory" (Y-0-0069)
 - "Position command value smoothing filter time constant" (P-0-0099)
 - "Command value generator dwell time" (Y-0-0057)

The following parameters can be set with rotary axes:

- "Command value generator travel distance rotary" (Y-0-0065)
- "Command value generator velocity rotary" (Y-0-0062)
- "Positioning acceleration rotary"(Y-0-0070)
- "Position command value smoothing filter time constant" (P-0-0099)
- "Command value generator dwell time" (Y-0-0057)

3.2 Real Time Bits of the Oscilloscope Function

SERCOS interface offers a free parametrization of two real time control and status bits. Till now, SERCANS used real time control and status bit 1 to ensure a simultaneous oscilloscope triggering of several drives.

This version does not make it possible for the use to freely parametrize all real time bits. In this version, real time bit 1 can be used by switching SERCANS off.

| Bit 4 of Y-0-0001 "Bus mode" | Oscilloscope function possible ? | Free use of all real time bits ? |
|---------------------------------|-------------------------------------|-------------------------------------|
| 0 | yes | no |
| 1 | no | yes |

3.3 Noise Generator

General When starting up a machine axes it is not always possible to use the step response of the velocity or position control loop to determine the system's frequency. In such cases, a noise generator can be used. It makes a test signal without average available.

Function The noise generator makes a pseudo-static binary signal available. Its amplitude accepts positive and negative values. The drive receives a new command value during each SERCOS cycle.

The amplitude of the output signal can be scaled for the axis in use via parameter "amplitude noise source" (Y-0-0067).

The output signal is generated repeatedly about every 8 seconds given a SERCOS cycle time of 2 ms. The repetition time t_W of the noise generator depends on the "SERCOS cycle time" (Y-0-0004) and is computed as follows:

$$t_W = 2^{12} \cdot t_{Syc}$$

The noise signal can be switched on in any command value generator mode and is added to the relevant command value. This takes place by setting bit 5 in parameter "command value generator control word" (Y-0-0053).

Activation The noise generator can be activated as long as the command value generator has been started and drive enable is set. If the drive enable is removed, then the noise generator stops.

Parameter The following parameters can be set with rotary and translatory axes:

- "Amplitude noise source" (Y-0-0067)
- "Command value generator control word" (Y-0-0053)
- "Command value generator enable" (Y-0-0044)
- "SERCOS cycle time" (Y-0-0004)
- all parameters of the command value generator operating mode.

3.4 List of Measured Values

- General Information** An external signal analyzer, e.g., a Hewlett Pack HP 35670A, can be used to evaluate the system response to the noise signal. It receives its information via an analog output of the drives.
- If no external signal analyzer is available, then both existing internal lists of measured values can be used to compile measuring data. The contents of the list can then be evaluated with an external PC program.
- Function** Via parameter "command value generator operating mode axis structure 1..8" (Y-0-0045 to Y-0-0052) are selected, in addition to the command value generator operating mode, as of described in DOK-SERCAN-SER-05VRS**-AW01-EN-P, section 8 "command value generator functions", in bits 12 to 15 of the measuring signals wanted. The existing lists which are made up of 4,096 elements and used for the command and actual values, are filled with measuring data after bit 6 is set in parameter "command value generator control word" (Y-0-0053). The drive queries the measuring data in the SERCOS cycle. Upon completion of the measuring transaction, bit 6 of parameter "command value generator control word" (Y-0-0053) is automatically reset. The lists can now be read out by querying parameter "list of scope data 1 noise source" (Y-0-0068) and "list of scope data 2 noise source" (Y-0-0072) and, if necessary, stored in a file on the PC or evaluated online in the control.
- Activation** The process of selecting the measured values can only take place in phase 2.
- The measuring procedure can be activated as long as command value generator is started and drive enable applied. Once all data are compiled, the process is automatically stopped.
- Parameter** The following parameters can be set with both rotary and translatory axes:
- "Command value generator operating mode axis structure 1..8" (Y-0-0045 to Y-0-0052)
 - "Command value generator control word" (Y-0-0053)
- The measurands are stored in both of the following parameters:
- "List of scope data 1 noise source" (Y-0-0068)
 - "List of scope data 2 noise source" (Y-0-0072)

3.5 New Monitor Functions

The SERCANS monitor was expanded with two options:

- a cyclic reading of any internal address and
- a cyclic writing of a value to any address

This accessing is possible via command line *RZA <address>* for cyclic reading and *WZA <address> <data>* for cyclic writing.

3.6 New Interrupts in the Status Register

SERCANS can use the interrupt status register to trigger interrupts to the NC control unit. It can also

- signal a system error and
- acknowledge an MMI service channel transmission as part of the drive independant operations.

In drive-related terms

- NC service channel transmission are acknowledged,
- a change in drive warnings (see parameter Y-0-0001),
- a change in drive messages (see parameter Y-0-0001),
- changes in command acknowledge are displayed and
- drive diagnostics are signalled.

The following interrupt has been added to version 05:

- Acknowledgement of bits 11 and 12 of the interrupt control register. Bit 11 signals that all parameters are stored (for bit 12) or all parameters have been activated (for bit 11).




Fig. 3-3: Interrupt status register

3.7 SERCOS Interface Version V01.1

This SERCANS version also supports drives of the SERCOS interface version V01.1, for example DIAX02 "SZU firmware". In all older SERCANS versions it was not possible to use the command value generator.

3.8 Validity of AT Data in the Actual Value Channel

The SERCOS interface standard permits a simple failure of a drive telegram. In this case, the data of the previous drive telegram are copied in the relevant axis structure.

The control can determine the validity of a drive telegram via the register "AT telegram invalid" in the Dual-Port-RAM (see DOK-SERCAN-SER-05VRS**-AW01-EN-P, section 9.1 "Memory Map Overview").




Fig. 3-4: Register "AT telegram invalid"

4 New or Altered Parameters

Y-0-0001 Bus mode

| Initial version | New Parameter ? | Altered Function ? |
|-----------------|-----------------|--------------------|
| 02VRS | | ✓ |
| 03VRS | | ✓ |
| 04VRS | | ✓ |


Bus mode can be used to institute the following settings:

- Bit 0 is used to allocate low and high words in the DPR with 4 byte values. Either an Intel allocation ('high word' to higher addresses) or a Motorola allocation ('high word' to lower addresses) is possible. SERCANS takes care of the word allocation specified here. The Intel format is normally used with SCS-P, while Motorola is used with SCS-V.
- Bit 1 can be used to enable or disable the DPR interrupt "drive messages" (class 3 diagnostics) in the interrupt status register.
- Bit 2 can be used to enable or disable the DPR interrupt "drive warnings" (class 2 diagnostics) in the interrupt status register.
- Bit 3 makes it possible to switch off the SERCANS internal calculation of communication parameters.

Note: If manual calculation of communication parameters is set in bit 3, then the communication parameters must be set in the drive. The standard setting is "automatic computation".

- With bit 4 the use of real time control and status bits 1 is fixed.

Note: If internal use is set in bit 4 (bit 4 equal to 1), then DriveTop **cannot** use the oscilloscope function!



Y-0-0001 Attribute

| | |
|-----------------------------|-----------------------------------|
| Data length: | 2 bytes |
| Display format: | binary number |
| Scaling / Unit: | 1 |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | 0 |
| Access: | write protected in operating mode |

Y-0-0044 Command value generator enable

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | ✓ |
| 04VRS | | ✓ |

The operating data of the command value generators are globally enabled with this parameter.

Note: Motions can be initiated via the parameters of the command value generator if bit 0 is set in this parameter! SERCANS ignores the command values of the control.

To ensure that no motion is triggered, it is necessary to set this parameter to zero! This setting validates the command values of the control in the dual port RAM and are activated by SERCANS.

Note: SERCANS sets this parameter to zero at each new start.




Fig. 4-1: Command value generator enable

This parameter is not used to set the operating mode of the individual axes but it can be used globally switch the command value generator function on and off.

Y-0-0044 Attribute

| | |
|-----------------------------|-----------------------------------|
| Data length: | 2 bytes |
| Display format: | binary number |
| Scaling / Unit: | — |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | 00000000.00000000 |
| Access: | write protected in operating mode |

Y-0-0045 Command value generator operating mode axis structure 1

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | ✓ |
| 04VRS | | ✓ |

This parameter is used to select the modes of the command value generator for axis structure 1.

Note: If the command value generator is switched off in parameter Y-0-0044, then this parameter is dormant.




Fig. 4-2: Operating mode of command value generator

A specific cyclically configured telegram is needed, but which is needed depends on the activated mode.

If the specified parameters are not configured in the cyclic telegram, then SERCANS will conduct the necessary configuration.

The original configuration is stored so that after the command value generator is deactivated, the control can once again control drive movements.

Y-0-0045 Attribute

| | |
|-----------------------------|-----------------------------------|
| Data length: | 2 bytes |
| Display format: | binary number |
| Scaling / Unit: | — |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | 00000000.00000000 |
| Access: | write protected in operating mode |

Y-0-0046 Command value generator operating mode axis structure 2

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0046 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0047 Command value generator operating mode axis structure 3

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0047 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0048 Command value generator operating mode axis structure 4

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0048 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0049 Command value generator operating mode axis structure 5

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0049 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0050 Command value generator operating mode axis structure 6

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0050 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input vaue: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0051 Command value generator operating mode axis structure 7

Y-0-0051 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0052 Command value generator operating mode axis structure 8

(see "command value generator operating mode axis structure 1", Y-0-0045)

Y-0-0052 Attributes

| | |
|-----------------------------|-----------------------------------|
| data length: | 2 bytes |
| display format: | binary number |
| scaling / unit: | -- |
| minimum input value: | -- |
| maximum input value: | -- |
| default value: | 00000000.00000000 |
| access: | write protected in operating mode |

Y-0-0053 Command value generator control word

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | ✓ |
| 04VRS | | ✓ |

Note: Bits 0 to 7 of this parameter are not stored resident. The value 0x0 is written into them with each runup and powering up of the system.

This parameter contains the control commands for command value generator. These commands are only instituted if bit 0 is set in parameter Y-0-0044.




Fig. 4-3: Control word of the command value generators

The physical drive addresses logically allocated in parameter Y-0-0012 are selected using bits 8 to 15. The choice is made by setting the relevant bit to "1".

Y-0-0053 Attribute

| | |
|-----------------------------|-------------------------------------|
| Data length: | 4 bytes |
| Display format: | binary number |
| Scaling / Unit: | — |
| Minimum input value: | 0 |
| Maximum input value: | 11111111.11111111.11111111.11111111 |
| Default value: | 00000000.00000000.00000000.00000000 |
| Access: | not write protected |

Y-0-0054 Command value generator position 1 translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is active only with translatory scaling of the axis. It has the following definition, depending on the set command value generator function:

Reversing with velocity control Movements with negative velocity value ("command value generator velocity translatory", Y-0-0056) cyclically check whether this position is succeeded. If so, then the velocity command goes to 0.

Reversing with position control Movements with negative value ("command value generator velocity translatory", Y-0-0056) run to this position.

Y-0-0054 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10 ⁻⁴ mm |
| Minimum input value: | -274748,3648 |
| Maximum input value: | 214748,3647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0055 Command value generator position 2 translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is only active with translatory scaling of axes.

Reversing with velocity control

Movements with positive velocity value ("command value generator velocity translatory", Y-0-0056) are cyclically checked as to whether this position is exceeded. If so, then velocity command goes to 0.

Reversing with position control

Movements with positive value ("command value generator velocity translatory") run to this position.

Y-0-0055 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10 ⁻⁴ mm |
| Minimum input value: | -214748,3648 |
| Maximum input value: | 214748,3647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0056 Command value generator velocity translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | ✓ |
| 04VRS | | ✓ |

This parameter is only active with translatory scaling of the axes. It writes the velocity into command value generator operating mode "reversing" and "step mode".

Y-0-0056 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | mm/min |
| Minimum input value: | -2147483.648 |
| Maximum input value: | +2147483.647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0057 Command value generator dwell time

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

The duration with which the drive remains at the position last reached before travelling to the next position is set in this parameter. It only affects functions "reversing" and "step mode".

Y-0-0057 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 2 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 ms |
| Minimum input value: | 0 |
| Maximum input value: | 10000 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0058 Command value generator jogging speed translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is only active with translatory scaling of axes and in "velocity control mode". It specifies the jogging velocity of the drive.

Y-0-0058 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10 ⁻³ mm/min |
| Minimum input value: | -2147483,648 |
| Maximum input value: | 2147483,647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0059 Command value generator status word

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | ✓ |
| 04VRS | | |

This parameter contains the acknowledge of the received control command for the command value generator. The single bits are only set if the command is executed without an error. Bit assignment precisely corresponds to parameter "command value generator control word" (Y-0-0053).




Fig. 4-4: Command value generator status word

Bits 8 to 15 show the physical drive addresses logically allocated in parameter Y-0-0012.

Y-0-0059 Attribute

| | |
|-----------------------------|-----------------|
| Data length: | 4 Byte |
| Display format: | binary number |
| Scaling / Unit: | — |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | — |
| Access: | write protected |

Possible Causes for Non-Acknowledged Control Commands

- Value 0x0000 has been set in parameter Y-0-0044.
- If drive enable is not set or acknowledged, then jogging is not possible and the command value generator not started.
- If jogging is still active, then reverse and step mode cannot be started. The same applies in the opposite case.
- If the drive is receiving no power or if it is signalling an error, then drive enable will not be acknowledged.
- SERCANS firmware checks whether communication via serial interface has occurred. At the end of timeout after the last communication, the command value generator is stopped to avoid unwanted axis motions.

Y-0-0060 Command value generator position 1 rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is active only with rotary scaling of the axis. It has the following definition, depending on the set command value generator function:

Reversing with velocity control

Movements with the negative velocity value ("command value generator velocity rotary", Y-0-0062) are checked cyclically as to whether position is succeeded. If so, then velocity command value goes to 0.

Reversing with position control

Movements with negative velocity value ("command value generator velocity rotary") run to this position.

Y-0-0060 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10^{-4} degrees |
| Minimum input value: | -214748,3648 |
| Maximum input value: | 214748,3647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0061 Command value generator position 2 rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is only active with rotary scaling of axes.

Reversing with velocity control

Movements with positive velocity value ("command value generator velocity rotary", Y-0-0062) cyclically check whether this position is exceeded. If so, then the velocity command value goes to 0.

Reversing with position control

Movements with positive velocity value ("command value generator velocity rotary") run to this position.

Y-0-0061 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10^{-4} degrees |
| Minimum input value: | -214748,3648 |
| Maximum input value: | 214748,3647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0062 Command value generator velocity rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is only effective with rotary axis scaling. It sets the velocity in the command value generator mode "reversing" and "step mode".

Y-0-0062 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 1 rpm |
| Minimum input value: | -200000.0000 |
| Maximum input value: | +200000.0000 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0063 Command value generator jogging speed rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is only active with rotary scaling of axes and in "velocity control mode". It specifies the jogging velocity of the drive.

Y-0-0063 Attribute

| | |
|-----------------------------|-----------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 10^{-4} 1/min |
| Minimum input value: | -214748,3648 |
| Maximum input value: | 214748,3647 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0064 Command value generator travel distance translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter only affects function "step mode". It has the following definition, depending on the operating mode set:

- Velocity control** Movements with negative or positive velocity values ("command value generator translatory or rotary") are cyclically checked whether, starting with the present position, the new relative target position Δx has been exceeded. If so, then velocity is set to 0.
- Position control** Movements with negative or positive velocity values ("command value generator velocity translatory or rotary") are approached starting with the present position and going to the new relative target position Δx .

Y-0-0064 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 4 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 10^{-4} mm |
| Minimum input value: | 0 |
| Maximum input value: | 429496,7295 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0065 Command value generator travel distance rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | | |
| 04VRS | | |

This parameter is effective with function "reversing" and "step mode". It has the following definition, depending on the mode set:

| | |
|-------------------------|--|
| Velocity control | Movements with negative or positive velocity values ("command value generator translatory or rotary") are cyclically checked whether, starting with the present position, the new relative target position Δx has been exceeded. If so, then velocity command value is set to 0. |
| Position control | Movements with negative or positive velocity value ("command value generator velocity translatory or rotary") are approached starting with the present position and going to the new relative target position Δx . |

Y-0-0065 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 4 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 10^{-4} degrees |
| Minimum input value: | 0 |
| Maximum input value: | 429496,7295 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0066 List of telegram type parameter

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | |

The choice can be made in this list between standard telegrams (input 0-6) and application telegrams (input 7).

Configuration of real time data (telegrams) is explained in section 8.

Possible inputs are:




Fig. 4-5: Element structure




Fig. 4-6: List structure (Y-0-0066)

Y-0-0066 Attribute

| | |
|-----------------------------|--|
| Data length: | 2 Byte var. length (Max: 16 Byte) |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 |
| Minimum input value: | 0 |
| Maximum input value: | 15 |
| Default value: | 0016 (act. length) 0016 (max. length) |
| Access: | write protected in operating mode |

Y-0-0067 Amplitude noise source

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | ✓ |

This parameter sets the output amplitude of the noise generator with translatory scaling.

Note: To superimpose a noise signal over the movement of the command value generator it is necessary to switch it on in parameter Y-0-0053.

Y-0-0067 Attribute

| | |
|-----------------------------|-------------------------------|
| Data length: | 4 Byte |
| Display format: | signed decimal number |
| Scaling / Unit: | 1 degrees, mm, rpm, mm/min, % |
| Minimum input value: | 0.001 |
| Maximum input value: | +429496.7295 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0068 List of scope data 1 noise source

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | ✓ |

This parameter contains the measured command values of the command value generator.

Y-0-0068 Attribute

| | |
|-----------------------------|------------------------------------|
| Data length: | 4 Byte var. length (Max: 16 kByte) |
| Display format: | signed decimal number |
| Scaling / Unit: | 1 degrees, mm, rpm, mm/min, % |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | — |
| Access: | write protected |

Y-0-0069 Positioning acceleration translatory

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | ✓ |

This parameter is only effective with translatory scaling of the axis and command generator modes in position control. It specifies the positioning velocity.

Y-0-0069 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 4 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 mm/sec ² |
| Minimum input value: | 0 |
| Maximum input value: | +4294967.295 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0070 Positioning acceleration rotary

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | ✓ |

This parameter is only effective with rotary scaling of the axis and command generator modes in position control. It specifies the positioning velocity.

Y-0-0070 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 4 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 rad/sec ² |
| Minimum input value: | 0 |
| Maximum input value: | +4294967.295 |
| Default value: | 0 |
| Access: | not write protected |

Y-0-0071 Powering up target phase

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | | |

This phase is automatically reached after switching on the SERCANS assembly.

Y-0-0071 Attribute

| | |
|-----------------------------|-------------------------|
| Data length: | 2 Byte |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 |
| Minimum input value: | 0 |
| Maximum input value: | 4 |
| Default value: | 4 |
| Access: | not write protected |

Y-0-0072 List of scope data 2 noise source

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | ✓ | |

This parameter contains the measured actual values of the command value generator.

Y-0-0072 Attribute

| | |
|-----------------------------|------------------------------------|
| Data length: | 4 Byte var. length (Max: 16 kByte) |
| Display format: | signed decimal number |
| Scaling / Unit: | 1 degrees, mm, rpm, mm/min, % |
| Minimum input value: | — |
| Maximum input value: | — |
| Default value: | — |
| Access: | write protected |

Y-0-0073 List of error counter AT

| Initial version | New Parameter ? | Altered function ? |
|-----------------|-----------------|--------------------|
| 02VRS | ✓ | |
| 03VRS | ✓ | |
| 04VRS | ✓ | |

This parameter counts the simple AT failures in communication phases 3 and 4.

If two sequential ATs of a drive fail, then error "Double AT failure" is generated.

"Error counter AT" only counts to 65535 and then stops. This value is only reached if there is severe interference in transmissions over an extended period of time.

To reset the counter, write access it.




Fig. 4-7: List structure (Y-0-0073)

Y-0-0073 Attribute

| | |
|-----------------------------|---|
| Data length: | 2 Byte var. length (Max: 16 Byte) |
| Display format: | unsigned decimal number |
| Scaling / Unit: | 1 |
| Minimum input value: | 0 |
| Maximum input value: | 65535 |
| Default value: | 0016 (act. length) 0016 (max. length) 0000 ... 0000 |
| Access: | not write protected |

5 Kundenbetreuungsstellen - Sales & Service Facilities

Deutschland – Germany

vom Ausland: (0) nach Landeskennziffer weglassen!!
from abroad: don't dial (0) after country code!

| | | | |
|--|---|---|---|
| Vertriebsgebiet Mitte <input checked="" type="checkbox"/> SALES Germany Centre <input checked="" type="checkbox"/> Service Rexroth Indramat GmbH Bgm.-Dr.-Nebel-Str. 2 97816 Lohr am Main Telefon: +49 (0)9352/40-0 Telefax: +49 (0)9352/40-4885 | Vertriebsgebiet Mitte <input checked="" type="checkbox"/> SALES Germany Centre <input type="checkbox"/> Service Mannesmann Rexroth AG Gesch.ber. Rexroth Indramat Lilistraße 14-18 63067 Offenbach Telefon: +49 (0) 69/82 00 90-0 Telefax: +49 (0) 69/82 00 90-80 | Vertriebsgebiet Ost <input checked="" type="checkbox"/> SALES Germany East <input checked="" type="checkbox"/> Service Rexroth Indramat GmbH Beckerstraße 31 09120 Chemnitz Telefon: +49 (0)371/35 55-0 Telefax: +49 (0)371/35 55-333 | Vertriebsgebiet Ost <input checked="" type="checkbox"/> SALES Germany East <input type="checkbox"/> Service Mannesmann Rexroth AG GB Rexroth Indramat GmbH Holzhäuser Str. 122 04299 Leipzig Telefon: +49 (0)341/86 77-0 Telefax: +49 (0)341/86 77-219 |
| Vertriebsgebiet Süd <input checked="" type="checkbox"/> SALES Germany South <input type="checkbox"/> Service Rexroth Indramat GmbH Ridlerstraße 75 80339 München Telefon: +49 (0)89/540138-30 Telefax: +49 (0)89/540138-10 indramat.mue@t-online.de | Gebiet Südwest <input checked="" type="checkbox"/> SALES Germany South-West <input checked="" type="checkbox"/> Service Mannesmann Rexroth AG Vertrieb Deutschland – VD-BI Geschäftsbereich Rexroth Indramat Regionalzentrum Südwest Ringstrasse 70 / Postfach 1144 70736 Fellbach / 70701 Fellbach Tel.: +49 (0)711/57 61–100 Fax: +49 (0)711/57 61–125 | Vertriebsgebiet Nord <input checked="" type="checkbox"/> SALES Germany North <input type="checkbox"/> Service Rexroth Indramat GmbH Kieler Straße 212 22525 Hamburg Telefon: +49 (0)40/85 31 57-0 Telefax: +49 (0)40/85 31 57-15 | Vertriebsgebiet Nord <input checked="" type="checkbox"/> SALES Germany North <input type="checkbox"/> Service Mannesmann Rexroth AG Vertriebsniederlassung Region Nord Gesch.ber. Rexroth Indramat Walsroder Str. 93 30853 Langenhagen Telefon: +49 (0) 511/72 66 57-0 Telefax: +49 (0) 511/72 66 57-93 |
| Vertriebsgebiet West <input checked="" type="checkbox"/> SALES Germany West <input checked="" type="checkbox"/> Service Mannesmann Rexroth AG Vertrieb Deutschland Regionalzentrum West Borsigstrasse 15 D - 40880 Ratingen Telefon: +49 (0)2102/409-0 Telefax: +49 (0)2102/409-406 | SERVICE - Hotline - 7 Tage / 24h - HELPDESK MO – FR - von 7 – 17 Uhr Telefax +49 (0)9352/40-4941 Telefon +49 (0)9352/40- Bernard A. -4894 Kolb R. -4922 Pfeffermann O. -4808 Roeper P. -4359 Scheiner W. -4921 AUSSERHALB dieser Zeit: Telefon: +49 (0)172/660 04 06 oder/or Telefon: +49 (0)171/333 88 26 | | ERSATZTEIL - Hotline ♦ nur an Werktagen ♦ von 15 -18 Uhr Tel. +49 (0) 93 52/40 42 22 |

Kundenbetreuungsstellen in Deutschland - Service agencies in Germany

Europa – Europe

vom Ausland: (0) nach Landeskennziffer weglassen,
from abroad: don't dial (0) after country code,

0 nach Landeskennziffer mitwählen!
dial 0 after country code!

| | | | |
|--|---|--|--|
| <p>Austria <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth Ges.m.b.H. Gesch.ber. Rexroth Indramat Hägelingasse 3 A - 1140 Wien</p> <p>Telefon: +43 (0)1/9852540-400 Telefax: +43 (0)1/9852540-93</p> | <p>Austria <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth G.m.b.H. Gesch.ber. Rexroth Indramat Industriepark 18 A - 4061 Pasching</p> <p>Telefon: +43 (0)7221/605-0 Telefax: +43 (0)7221/605-21</p> | <p>Belgium <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth N.V.-S.A. Gesch.ber. Rexroth Indramat Industrielaan 8 B-1740 Ternat</p> <p>Telefon: +32 (0)2/5830719 Telefax: +32 (0)2/5830731</p> | <p>Denmark <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>BEC AS Zinkvej 6 DK-8900 Randers</p> <p>Telefon: +45 (0)87/11 90 60 Telefax: +45 (0)87/11 90 61</p> |
| <p>England <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Ltd. Rexroth Indramat Division Broadway Lane, South Cerney GB - Cirencester, Glos GL7 5UH</p> <p>Telefon: +44 (0)1285/863000 Telefax: +44 (0)1285/863030</p> <p>sales@indramat.co.uk service@indramat.co.uk</p> | <p>Finland <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Rexroth Mecman Oy Rexroth Indramat division Ansatie 6 SF-017 40 Vantaa</p> <p>Telefon: +358 (0)9/84 91-11 Telefax: +358 (0)9/84 91-13 60</p> | <p>France <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A. Division Rexroth Indramat Parc des Barbanniers 4, Place du Village F-92632 Gennevilliers Cedex</p> <p>Telefon: +33 (0)141 47 54 30 Telefax: +33 (0)147 94 69 41 Hotline: +33 (0)6 08 33 43 28</p> | <p>France <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A. Division Rexroth Indramat 270, Avenue de Lardenne F - 31100 Toulouse</p> <p>Telefon: +33 (0)5 61 49 95 19 Telefax: +33 (0)5 61 31 00 41</p> |
| <p>France <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A. Division Rexroth Indramat 91, Bd. Irène Joliot-Curie F - 69634 Vénissieux – Cedex</p> <p>Telefon: +33 (0)4 78 78 53 65 Telefax: +33 (0)4 78 78 53 62</p> | <p>Italy <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via G. Di Vittoria, 1 I - 20063 Cernusco S/N.MI</p> <p>Telefon: +39 02/92 36 52 70 Telefax: +39 02/92 36 55 12</p> | <p>Italy <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via Borgomanero, 11 I - 10145 Torino</p> <p>Telefon: +39 011/7 50 38 11 Telefax: +39 011/7 71 01 90</p> | <p>Italy <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via del Progresso, 16 (Zona Ind.) I - 35020 Padova</p> <p>Telefon: +39 049/8 70 13 70 Telefax: +39 049/8 70 13 77</p> |
| <p>Italy <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via Mascia, 1 I - 80053 Castellammare di Stabia NA</p> <p>Telefon: +39 081/8 71 57 00 Telefax: +39 081/8 71 68 86</p> | <p>Italy <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Viale Oriani, 38/A I - 40137 Bologna</p> <p>Telefon: +39 051/34 14 14 Telefax: +39 051/34 14 22</p> | <p>Netherlands <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Hydraudyne Hydrauliek B.V. Kruisbroeksestraat 1 (P.O. Box 32) NL - 5281 RV Boxtel</p> <p>Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/65 14 83 e-mail: indramat@hydraudyne.nl</p> | <p>Netherlands <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Hydrocare B.V. Kruisbroeksestraat 1 (P.O. Box 32) NL - 5281 RV Boxtel</p> <p>Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/67 78 14</p> |
| <p>Norway <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Rexroth Mecman AS Rexroth Indramat Division Berghagan 1 or: Box 3007 N -1405 Ski-Langhus N -1402 Ski</p> <p>Telefon: +47 (0)64 86 41 00 Telefax: +47 (0)64 86 90 62</p> <p>jul.ruud@rexroth.no</p> | <p>Poland <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth Sp.zo.o. Biuro Poznan ul. Dabrowskiego 81/85 PL - 60-529 Poznan</p> <p>Telefon: +48 061/847 67 99 Telefax: +48 061/847 64 02</p> | <p>Russia <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Tschudnenko E.B. Arsenia 22 RUS - 153000 Ivanovo Rußland</p> <p>Telefon: +7 093/223 96 33 oder/or +7 093/223 95 48 Telefax: +7 093/223 46 01</p> | <p>Spain <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A. División Rexroth Indramat Centro Industrial Santiga Obradors s/n E-08130 Santa Perpetua de Mogoda Barcelona</p> <p>Telefon: +34 937 47 94 00 Telefax: +34 937 47 94 01</p> |
| <p>Spain <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Goimendi S.A. División Rexroth Indramat Jolastokieta (Herrera) Apartado 11 37 E - 20017 San Sebastian</p> <p>Telefon: +34 9 43/40 01 63 Telefax: +34 9 43/39 17 99</p> | <p>Sweden <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Rexroth Mecman Svenska AB Rexroth Indramat Division Varuvägen 7 S - 125 81 Stockholm</p> <p>Telefon: +46 (0)8/727 92 00 Telefax: +46 (0)8/647 32 77</p> | <p>Slovenia <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Rexroth Indramat elektromotorji d.o.o. Otoki 21 SLO - 64 228 Zelezniki</p> <p>Telefon: +386 64/61 73 32 Telefax: +386 64/64 71 50</p> | <p>Turkey <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Hidropar A.S. Fevzi Cakmak Cad No. 3 TR - 34630 Sefaköy Istanbul</p> <p>Telefon: +90 212/541 60 70 Telefax: +90 212/599 34 07</p> |
| <p>Switzerland <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service -East-</p> <p>Mannesmann Rexroth Schweiz AG Gesch.ber. Rexroth Indramat Gewerbstraße 3 CH - 8500 Frauenfeld</p> <p>Telefon: +41 (0)52/720 21 00 Telefax: +41 (0)52/720 21 11</p> | <p>Switzerland <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service -West-</p> <p>Mannesmann Rexroth Suisse SA Département Rexroth Indramat Rue du village 1 CH - 1020 Renens</p> <p>Telefon: +41 (0)21/632 84 20 Telefax: +41 (0)21/632 84 21</p> | | <p>rexroth@cea.ru</p> |

Europäische Kundenbetreuungsstellen (ohne Deutschland)
European Service agencies (without Germany)

Außerhalb Europa - outside Europe

vom Ausland:
from abroad:

(0) nach Landeskenziffer weglassen!
don't dial (0) after country code!

| | | | |
|---|--|---|--|
| <p>Argentina <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth S.A.I.C. Division Rexroth Indramat Acassuso 48 41/7 RA - 1605 Munro (Buenos Aires) Telefon: +54 (0)11/4756 01 40 Telefax: +54 (0)11/4762 6862 e-mail:mannesmann@impsat1.com.ar</p> | <p>Argentina <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>NAKASE Servicio Tecnico CNC Calle 49, No. 5764/66 RA - 1653 Villa Balester Prov. - Buenos Aires Telefon: +54 (0) 11/4768 36 43 Telefax: +54 (0) 11/4768 24 13 e-mail: nakase@usa.net nakase@infovia.com.ar</p> | <p>Australia <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>AIMS - Australian Industrial Machinery Services Pty. Ltd. Unit 3/45 Horne ST Campbellfield , VIC 3061 AUS - Melbourne Telefon: +61 (0)3/93 59 02 28 Telefax: +61 (0)3/93 59 02 86</p> | <p>Australia <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth Pty. Ltd. No. 7, Endeavour Way Braeside Victoria, 31 95 AUS - Melbourne Telefon: +61 (0)3/95 80 39 33 Telefax: +61 (0)3/95 80 17 33 Email:mel@rexroth.com.au</p> |
| <p>Brazil <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Automação Ltda. Divisão Rexroth Indramat Rua Georg Rexroth, 609 Vila Padre Anchieta BR - 09951-270 Diadema-SP [Caixa Postal 377] [BR-09901-970 Diadema-SP] Telefon: +55 (0)11/745 90 60 +55 (0)11/745 90 70 Telefax: +55 (0)11/745 90 50 e-mail: awittwer@rexroth.com.br</p> | <p>Brazil <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Automação Ltda. Divisão Rexroth Indramat R. Dr.Humberto Pinheiro Vieira, 100 Distrito Industrial BR - 89220-390 Joinville - SC [Caixa Postal 1273] Tel./Fax: +55 (0)47/473 58 33 Mobil: +55 (0)47 974 66 45 e-mail: :prochnow@zaz.com.br</p> | <p>Canada <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Basic Technologies Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8 Telefon: +1 905/335 55 11 Telefax: +1 905/335-41 84</p> | <p>China <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth (China) Ltd. Shanghai Parts & Service Center 199 Wu Cao Road, Hua Cao Minhang District PRC - Shanghai 201 103 Telefon: +86 21/62 20 00 58 Telefax: +86 21/62 20 00 68</p> |
| <p>China <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth (China) Ltd. 15/F China World Trade Center 1, Jianguomenwai Avenue PRC - Beijing 100004 Telefon: +86 10/65 05 03 80 Telefax: +86 10/65 05 03 79</p> | <p>China <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District PRC - Dalian 116 023 Telefon: +86 411/46 78 930 Telefax: +86 411/46 78 932</p> | <p>Hongkong <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Rexroth (China) Ltd. 1/F., 19 Cheung Shun Street Cheung Sha Wan, Kowloon, Hongkong Telefon: +852 22 62 51 00 Telefax: +852 27 44 02 78</p> | <p>India <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth (India) Ltd. Rexroth Indramat Division Plot. 96, Phase III Peenya Industrial Area IND - Bangalore - 560058 Telefon: +91 (0)80/8 39 73 74 Telefax: +91 (0)80/8 39 43 45</p> |
| <p>India <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth (India) Ltd. Rexroth Indramat Division Plot. A-58, TTC Industrial Area Thane Turbhe Midc Road Mahape Village IND - Navi Mumbai - 400 701 Telefon: +91 (0)22/7 61 46 22 Telefax: +91 (0)22/7 68 15 31</p> | <p>Indonesia <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>PT. Rexroth Wijayakusuma Jl. Raya Bekasi Km 21 Pulogadung RI - Jakarta Timur 13920 Telefon: +62 21/4 61 04 87 +62 21/4 61 04 88 Telefax: +62 21/4 60 01 52</p> | <p>Japan <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Rexroth Automation Co., Ltd. Service Center Japan Yutakagaoka 1810, Meito-ku, NAGOYA 465-0035, Japan Telefon: +81 (0)52/777 88 41 +81 (0)52/777 88 53 +81 (0)52/777 88 79 Telefax: +81 (0)52/777 89 01</p> | <p>Japan <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Rexroth Automation Co., Ltd. Rexroth Indramat Division 1F, I.R. Building Nakamachidai 4-26-44, Tsuzuki-ku YOKOHAMA 224-0041, Japan Telefon: +81 (0)45/942 72 10 Telefax: +81 (0)45/942 03 41</p> |
| <p>Mexico <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Mannesmann Rexroth Mexico S.A. de C.V. Calle Neptuno 72 Unidad Ind. Vallejo MEX - 07700 Mexico, D.F. Telefon: +52 5 754 17 11 +52 5 754 36 84 +52 5 754 12 60 Telefax: +52 5 754 50 73 +52 5 752 59 43 e-mail: gsoria@rexroth-mexico.com</p> | <p>Korea <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth-Seki Co Ltd. 1500-12 Da-Dae-Dong ROK - Saha-Ku, Pusan, 604-050 Telefon: +82 (0)51/2 60 06 18 Telefax: +82 (0)51/2 60 06 19</p> | <p>Korea <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Seo Chang Corporation Ltd. Room 903, Jeail Building 44-35 Yeouido-Dong Yeoungdeungpo-Ku C.P.O.Box 97 56 ROK - Seoul Telefon: +82 (0)2/7 80 82 08 +82 (0)2/7 80 82 09 Telefax: +82 (0)2/7 84 54 08</p> | <p>South Africa <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>TECTRA Automation (Pty) Ltd. 28 Banfield Road, Industria North RSA - Maraisburg 1700 Telefon: +27 (0)11/673 20 80 Telefax: +27 (0)11/673 72 69 georgv@hyauto.com</p> |
| <p>Taiwan <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service</p> <p>Rexroth Uchida Co., Ltd. No.1, Tsu Chiang Street Tu Cheng Ind. Estate Taipei Hsien, Taiwan, R.O.C. Telefon: +886 2/2 68 13 47 Telefax: +886 2/2 68 53 88</p> | | <p>minteke@ms2.hinet.net</p> | |

Kundenbetreuungsstellen außerhalb Europa - Service agencies outside Europe

Außerhalb Europa / USA - outside Europe / USA

| | | | |
|---|--|---|---|
| <p>USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Corporation Rexroth Indramat Division 5150 Prairie Stone Parkway USA -Hoffman Estates, IL 60192-3707</p> <p>Telefon: +1 847/6 45 36 00 Telefax: +1 847/6 45 62 01 service@indramat.com</p> | <p>USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Corporation Rexroth Indramat Division Central Region Technical Center USA - Auburn Hills, MI 48326</p> <p>Telefon: +1 248/3 93 33 30 Telefax: +1 248/3 93 29 06</p> | <p>USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Corporation Rexroth Indramat Division Southeastern Technical Center 3625 Swiftwater Park Drive USA - Suwanee Georgia 30174</p> <p>Telefon: +1 770/9 32 32 00 +1 770/9 32 19 03</p> | <p>USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Corporation Rexroth Indramat Division Northeastern Technical Center 99 Rainbow Road USA - East Granby, Connecticut 06026</p> <p>Telefon: +1 860/8 44 83 77 +1 860/8 44 85 95</p> |
| <p>USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service</p> <p>Mannesmann Rexroth Corporation Rexroth Indramat Division Charlotte Regional Sales Office 14001 South Lakes Drive USA - Charlotte, North Carolina 28273</p> <p>Telefon: +1 704/5 83 97 62 +1 704/5 83 14 86</p> | | | <p>USA Service HOTLINE</p> <p>+1-800-860-1055</p> <p>- 7 days / 24hrs -</p> |

Kundenbetreuungsstellen außerhalb Europa / USA
Service agencies outside Europe / USA

287007

Printed in Germany